


Pin Connections for:

Interface board for Stepper Motor Driver 4.2A to 7.8A



Parallel port pins for Step and Direction:

	Step	Direction
Axis X	2	3
Axis Y	5	4
Axis Z	7	6
Axis A	9	8