

Dialog 4422 IP Office / Dialog 4425 IP Vision
BusinessPhone Communication Platform
Quick Reference Guide



ASTRA

File Name: Dialog 4422 Ip Office User Manual.pdf

Size: 4113 KB

Type: PDF, ePub, eBook

Category: Book

Uploaded: 30 May 2019, 18:24 PM

Rating: 4.6/5 from 581 votes.

Status: AVAILABLE

Last checked: 7 Minutes ago!

In order to read or download Dialog 4422 Ip Office User Manual ebook, you need to create a FREE account.

[Download Now!](#)

eBook includes PDF, ePub and Kindle version

☐ [Register a free 1 month Trial Account.](#)

☐ [Download as many books as you like \(Personal use\)](#)

☐ [Cancel the membership at any time if not satisfied.](#)

☐ [Join Over 80000 Happy Readers](#)

Book Descriptions:

We have made it easy for you to find a PDF Ebooks without any digging. And by having access to our ebooks online or by storing it on your computer, you have convenient answers with Dialog 4422 Ip Office User Manual . To get started finding Dialog 4422 Ip Office User Manual , you are right to find our website which has a comprehensive collection of manuals listed.

Our library is the biggest of these that have literally hundreds of thousands of different products represented.



Book Descriptions:

Dialog 4422 Ip Office User Manual

User Guide Cover Page Graphic Place the graphic directly on the page, do not care about putting it in the text flow. Top 5,3 cm Important!. Left 0,3 cm Important!. This text should then be hidden. All rights reserved. User Guide Cover Page Graphic Place the graphic directly on the page, do not care about putting it in the text flow. Top 5,3 cm Important!. Left 0,3 cm Important!. This text should then be hidden. All rights reserved. This guide describes the available features of the telephone when it is connected to MXONE or MD110. The functions and features available with this telephone are designed for easy use in all different telephone handling situations. The user guide describes the functions and features of the Dialog 4422 IP Office as it is programmed at delivery from the factory. There may be some differences in the way your phone is programmed. Please consult your system administrator if you need further Note The Dialog 4422 IP Office exists in two versions, version 1 and version 2. Underneath the telephone, version 1 is marked DBC 422 01 and version 2 is marked DBC 422. 3 02. Check to see which version you are using. Some markets use differing codes for some features. In this guide they are described using the most common code. The latest version of the user guide can be downloaded from 4 Dialog 4422 IP Office Welcome Copyright All rights reserved. No parts of this publication may be reproduced, stored in retrieval systems, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without prior written permission of the publisher except in accordance with the following terms. When this publication is made available on Aastra media, Aastra gives its consent to downloading and printing copies of the content provided in this file only for private use and not for redistribution. No parts of this publication may be subject to alteration, modification or commercial use. <https://condosalebangkok.com/userfiles/broaster-pressure-fryer-manual.xml>

- **dialog 4422 ip office user manual, ericsson dialog 4422 ip office user manual, dialog 4422 ip office user manual, dialog 4422 ip office user manual user, dialog 4422 ip office user manual download, dialog 4422 ip office user manual pdf, dialog 4422 ip office user manual free.**

Aastra will not be liable for any damages arising from use of an illegal modified or altered publication. 4 Aastra is a registered trademark of Aastra Technologies Limited. All other trademarks mentioned herein are the property of their respective owners. Warranty AASTRA MAKES NO WARRANTY OF ANY KIND WITH REGARD. Details to be found at Dialog 4422 IP Office 5. Important User Information Important User Information Safety instructions Save these instructions. 5 Read these safety instructions before use. Note When using your telephone or connected equipment, the following basic safety precautions should always be followed to reduce risk of fire, electrical shock and other personal injury. Follow instructions in the equipments user guide or other documentation. Always install equipment in a location and environment for which it is designed. For mains powered telephones Only operate with the mains power voltage indicated. If you are uncertain of the type of power supplied to the building, consult property management or your local power company. For mains powered telephones Avoid placing the telephones power cable where it can be exposed to mechanical pressure as this may damage the cable. If the power supply cord or plug is damaged, disconnect the product and contact qualified service personnel. Unauthorized changes or modifications could void the users authority to operate the equipment. Do not use the telephone to report a gas leak in the vicinity of the leak. Do not spill liquid of any kind on the product or use the equipment near water, for example, near a bathtub, washbowl, and kitchen sink, in a wet basement or near a swimming pool. Do not insert any object into equipment slots that is not part of the

product or auxiliary product. Do not disassemble the product. Contact a qualified service agency when service or repair work is required. Do not use a telephone other than cordless type during an electrical storm.<http://www.FlashPointIP.com/fckupload/brobo-waltdown-8sn-manual.xml>

Disposal of the product Your product should not be placed in municipal waste. Please check local regulations for disposal of electronic products.

7 6 Dialog 4422 IP Office Description Description 19.

1. Dialog 4422 IP Office 7 Conference Settings 2. 8 Transfer Follow me 3. Inquiry Message 4. 9 Line 2 Free on 2nd 5. Line 1 Call List 6. 21. DEF. ABC. GHI JKL MNO. 16. PQRS TUV WXYZ. 17 15. 10 11. 12 14. 20. 13. 18. Dialog 4422 IP Office 7. Description 1 Display See section Display information on page 14. 2 Settings Used to enter or leave setting mode. See sections Settings on page 77 and Menu structure Settings on page 19. This feature is mandatory and is programmed to this position by default. The features can be moved to any other programmable function key by the system administrator. The features can also be removed from the keys by your system administrator. In this case you can program frequently used features and phone numbers on the keys. 8 The keys can also be used as Monitoring keys or for assigning the features Callback, Call Pick up, Call Waiting and Intrusion. See sections Programming of function keys on page 78 and Key Monitoring on page 74. 3 Followme Indicates an activated Followme. Also used to deactivate Follow me. See section Call Forwarding on page 52. 4 Message Message indication key. When the key lamp is on, press the key to retrieve the message. See section Messages on page 64. 5 Free on 2nd Allow a second call to be received when you already have an active call. See section Answer a second call during an ongoing call on page 31. 6 Call List Used to access the list of outgoing and incoming calls. When the key lamp is flashing, there are unanswered incoming calls. See sections Redial calls from the Call List on page 38 and Call List. on page 44. 7 Conference Establish a conference. 9 See section Conference on page 50. 8 Transfer Transfer calls. See section Transfer on page 50. 8 Dialog 4422 IP Office Description 9 Triple Access Line Handle calls.

Line 1 and Line 2 are available both for incoming and outgoing calls. Inquiry can only be used for outgoing calls. 10 Mute a Switch the microphone on or off during a call. See section Mute on page 47. See section Settings on page 77. See section Settings on page 77. See section Redial calls from the Call List on page 38. See section Headset Preset on page 93. See section Settings on page 77. Off on page 20. For a description on how to use the Select key and Log on key, see section Hidden key functions on page 11. 13 Headset key Handle headset calls and activate Headset Preset. Can always be pressed instead of replacing the handset. See section Settings on page 77. Off on page 20. For a description on how to use the Exit key and Log off key, see section Hidden key functions on page 11. Show more HP Records Manager HPRM 8.1 Web Client Classic User Guide Section 2 To be completed by relevant Supervisor or Head of Budget Centre. Assessment of Conflict RMU Information Sheet 4. Subject. Disposal Schedules. Discover everything Scribd has to offer, including books and audiobooks from major publishers. Start Free Trial Cancel anytime. Report this Document Download Now Save Save Ericsson Dialog 4422 Ip Office PDF For Later 0 ratings 0% found this document useful 0 votes 38 views 2 pages Ericsson Dialog 4422 Ip Office PDF Uploaded by Rich Description Ericsson dialog 4422 ip office pdf Full description Save Save Ericsson Dialog 4422 Ip Office PDF For Later 0% 0% found this document useful, Mark this document as useful 0% 0% found this document not useful, Mark this document as not useful Embed Share Print Download Now Jump to Page You are on page 1 of 2 Search inside document Browse Books Site Directory Site Language English Change Language English Change Language. Please check your inbox, and if you can't find it, check your spam folder to make sure it didn't end up there. Please also check your spam folder.

<http://www.raumboerse-luzern.ch/mieten/bosch-washing-machine-1200-manual>

The BusinessPhone Communication Platform consists of BusinessPhone Compact, BusinessPhone 50, BusinessPhone 128i and BusinessPhone 250. There may be some differences in the way your phone is programmed. Please consult your system administrator if you need further information. Check to

see which version you are using. If DHCP is not supported by the LAN, please contact your system administrator. No parts of this publication may be reproduced, stored in retrieval systems, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without prior written permission of the publisher except in accordance with the following terms. No parts of this publication may be subject to alteration, modification or commercial use. Ericsson will not be liable for any damages arising from use of an illegal modified or altered publication. If you are uncertain of the type of power supplied to the building, consult property management or your local power company. If the power supply cord or plug is damaged, disconnect the product and contact qualified service personnel. Unauthorized. Contact a qualified service agency when service or repair work is required. Please check local regulations for disposal of electronic products. See section "Display Information " on page 12. See section " Settings " on page 75. Can be programmed as dial by name keys, function keys, etc. See section " Programmable Keys " on page 75. When the key lamp is flashing, there are unanswered incoming calls. See section " Call List " on page 35 The Designation Card Manager is included on the Telephone Toolbox CD for BusinessPhone Communication system which is part of the Quick Reference Guide. See section " Mute " on page 39. See section " Settings " on page 75. See section " Settings " on page 75. See section " Settings " on page 75. See section " Call List " on page 35. See section " During Calls " on page 37. See section " Accessories " on page 91.

<https://oooifc.com/images/Dcr--Hc45-Manual.pdf>

See section " Settings " on page 75. Can always be pressed instead of replacing the handset. See section " Settings " on page 75. See section " Log off " on page 25. Press the key to retrieve the message. See section " Access the Mailbox " on page 57. See section " Key panel " on page 91. Only the standard symbols are shown Volume, Loudspeaker and C. When an information ends with an exclamation mark !, this means that no further action is possible. When you are navigating through the menus, the selected menu is highlighted with a black frame. The special dial tone indicates an active diversion, an active absence information or waiting messages. After a power failure the phone will restart automatically. However, when a password is requested, you must log on before the phone can be used again. This procedure will also clear the Check the display on your phone and read the required sections in this chapter to continue with the start up procedure. After a power failure the Call List is cleared. In this case you must enter a valid user identity and password. The password is obtained from, and can only be changed by the system administrator. If no key is pressed during this time, "no change" is selected automatically. This mode is reserved for your system administrator. This takes about 1 minute. After a self test, the phone is ready for use or ready for log on. To log on, see section " Log on " on page 21 If no key is pressed during this time approximately. 60 seconds, "Yes" is selected automatically. You can speed up the procedure by pressing the Loudspeaker key. If a power failure occurs, the software must be downloaded again. This is the most common option. You cannot log on or off. This option can be used for phones in conference rooms, receptions etc. If the displayed number is your number The number for SOS calls might vary between countries. The request to enter a password can be changed, contact your system administrator.

<http://pandaplast.com/images/Dcr--Pc-330-Manual.pdf>

You can log on with your own extension number and get your personal categories. To get the letter A press key 2 once, for B press key 2 twice, to get C press key 2 three times, and so on. Every new word starts with an upper case character that is after a space has been entered. However, you can force the phone to enter all characters as upper case only, or lower case only, see below. This is only valid for the characters AZ. If you for example press 9, the following character options are shown on the display The text Log off is displayed. Stored numbers can consist of a maximum of 32 digits. This can also be used if no external line is free You have to answer within eight seconds, otherwise the

Callback service is cancelled. When the called extension replaces the Frequently used external numbers are stored as Common Abbreviated Numbers in the exchange. Common Abbreviated Numbers can be dialled from every extension that has the authority to do so. Stored numbers can consist of a maximum of 24 digits. For programming them, see chapter "Programmable Keys" on See section "Web Server" on page 98. You can switch between handset and monitoring, mute the microphone, make an inquiry, transfer the call, establish a conference or put the call on hold to perform other tasks.

<http://schlammatlas.de/en/node/18726>