



**File Name:** boss br 600 digital recorder manual.pdf

**Size:** 3423 KB

**Type:** PDF, ePub, eBook

**Category:** Book

**Uploaded:** 7 May 2019, 22:49 PM

**Rating:** 4.6/5 from 570 votes.

**Status:** AVAILABLE

Last checked: 9 Minutes ago!

**In order to read or download boss br 600 digital recorder manual ebook, you need to create a FREE account.**

[\*\*Download Now!\*\*](#)

eBook includes PDF, ePub and Kindle version

[Register a free 1 month Trial Account.](#)

[Download as many books as you like \(Personal use\)](#)

[Cancel the membership at any time if not satisfied.](#)

[Join Over 80000 Happy Readers](#)

### Book Descriptions:

We have made it easy for you to find a PDF Ebooks without any digging. And by having access to our ebooks online or by storing it on your computer, you have convenient answers with boss br 600 digital recorder manual . To get started finding boss br 600 digital recorder manual , you are right to find our website which has a comprehensive collection of manuals listed.

Our library is the biggest of these that have literally hundreds of thousands of different products represented.



## Book Descriptions:

# boss br 600 digital recorder manual

Stay up to date with Roland news, artists, promotions, events, and more. Provides an overview of key features, functions and operational tips. The BOSS Worldwide Social Network keeps you connected to the latest products, exciting events, and much more. Stay up to date with Roland news, artists, promotions, events, and more. Provides an overview of key features, functions and operational tips. The BOSS Worldwide Social Network keeps you connected to the latest products, exciting events, and much more. In no event shall Roland Corporation be liable to endusers for any damages whatsoever, including but not limited to financial damages for any loss of profits or information arising from the use of, or inability to use this updater. The foregoing provision is effective even if Roland Corporation has been advised of the possibility of such damages. Please read carefully the terms of this License Agreement before installing or using the SOFTWARE. By installing, copying, or starting the use of the SOFTWARE, you hereby consent to the terms of this License Agreement. Use of the SOFTWARE shall include loading the SOFTWARE into temporary memory i.e., RAM or installing the SOFTWARE into storage media i.e., hard disk of the computer on which you will use the SOFTWARE. Therefore, you must treat the SOFTWARE like any other copyrighted material i.e., a book or a CD. All rights that are not provided for herein are reserved by Roland. But you may permanently transfer the SOFTWARE and accompanying printed materials provided you retain no copies of the Software and recipient agrees to the terms of this License Agreement. If the SOFTWARE has been updated or upgraded, any transfer of the SOFTWARE must include the most recent update and all prior versions. You shall not use the remaining forms of media on another computer. Please read the instructions completely, and please note that you should use the SOFTWARE AT YOUR OWN

RISK. [http://www.marcth.pl/media/fck/construction-manual-concrete-u0026-formwork-by-t\\_w\\_love.xml](http://www.marcth.pl/media/fck/construction-manual-concrete-u0026-formwork-by-t_w_love.xml)

- **boss br 600 digital recorder manual pdf, boss br 600 digital recorder manual free, boss br 600 digital recorder manual online, boss br 600 digital recorder manual instructions, boss br 600 digital recorder manual 2017, boss br 600 digital recorder manual 2016, boss br 600 digital recorder manual downloads, boss br 600 digital recorder manual software, boss digital recorder br 600 manual.**

In no event shall Roland be liable to endusers for any damages whatsoever, including but not limited to financial damages for any loss of profits or information arising from the use of, or inability to use this product. The foregoing provision is effective even if Roland has been advised of the possibility of such damages. Even if the SOFTWARE has any material, verifiable, and reproducible program errors, Roland shall have no liability to modify such errors. Upon such termination, you shall immediately stop using the SOFTWARE. All rights reserved. The manual should be saved and kept. No part of this publication may be reproduced in any form. Used for instructions intended to alert the user to the risk of injury or material damage should the unit be used improperly. It can also run on six. This means operations such as copying and repeating a multiplebar phrase, moving a multiplebar phrase to another track, and erasing the data of a track, whole or in part, can be performed with ease. And, thanks to its an onboard stereo microphone, you can. The BR600 uses 32 MB to 1 GB CompactFlash cards with a 3.3 V power supply. For more on supported memory cards CompactFlash for the BR600, refer to "About Memory Cards". MIC1 dial This dial adjusts the sensitivity for MIC1 and the onboard stereo mic. The selected button will light. If the screen is difficult to view, see "Adjusting the Display Contrast" p. 190. 1. MEASURE Displays the current

position within the song. Turn over the BR600. Slide the battery cover in the direction indicated by the arrow and remove. When making any connections, make sure that all devices are turned off. fig.00110 Front Panel Electric Guitar Stereo Headphone Electric Bass Rear Panel AC Adaptor PSA series CD Player etc. Computer Foot Switch FS5U etc. To prevent the inadvertent disruption of power to your unit should the plug be pulled out accidentally, and to avoid applying undue stress to the AC adaptor jack, anchor the power cord using the cord

hook. <http://denetimmusavirlik.com/userfiles/construction-manual-birkhauser.xml>

When the power is first turned on, the demo song is automatically selected, and the data required for playback is loaded. You can create up to a maximum of 99 songs with the. Lower the MASTER fader. Turn the REC LEVEL dial to its center position and then slowly increase the MASTER fader. fig.00330 Adjust the recording level with the REC LEVEL dial. You should adjust the level so that the INPUT level meter fluctuates within the range from 12 between 24 and 6 to 0 dB. Below is an explanation of the operations related to the insert effects. What is an insert effect The BR600 is set to output sound without the insert effects applied, allowing you to record sounds without the insert effects. Selecting "INPUT " as the point to which. If the button flashes in red, that track is ready for recording. fig.00480 The status of each track can be determined from the indicator on the button. Use whichever mode is suitable in the course of bringing your song to completion. fig.00520 INPUT BOUNCE TRACK TRACK Guitar Bass Vocal Mixing down. The BR600 features eight audio tracks that can be used for recording and playback. Use the TRACK faders to adjust the volume separately for each track. Effective use of these allows you to add greater breadth to the sound. This enables you to select the combination of audio quality and recording time that is most suitable for the material you are recording. If the button flashes in red, that track is ready for recording. fig.00480 The status of each track can be determined from the indicator on the button. No recorded data exists on the track. You can select any one of these VTracks for recording or playback. This allows a wide range of uses, such as recording one take of a guitar solo or vocal, and then recording another take without having to erase the first one. Playback repeats in the portion set with Repeat as shown below. This may make it difficult for you to set the repeat portion exactly as you desire.

Recording automatically starts at the auto punchin location, so start playing what you want to record. This is called "bounce" also known as bounce recording or pingpong recording. If you do not want to record the Rhythm, lower the fader. First, insert the memory card containing the copy of the desired data into the BR600. This function is quite useful during editing. Registering a Locator Point At the Play screen, move to the location where you want to register the locator point. When you use the Scrub function during playback called "scrubbing", the portion from your before or after the. The display will ask "Are you sure," so that you can confirm the operation. By performing a "Song Optimize", you can have the BR600 erase any unnecessary data on the memory card and increase the unused space. These are grouped according to different input sources and each group is called a "bank.". If you wish to save the effect settings that you edited, save them as a user patch or song patch. However, sometimes you want to change the connection order. On the BR600, you can accommodate a wide variety of situations by changing the point to which the insert effects are connected. Follow the procedure below to change where insert effects are connected. The algorithms that can be selected will differ for each bank. To select the algorithm that you wish to use, first select the effect bank that includes that algorithm, and then refer to the "Effect Patch List". Those companies are not affiliated with BOSS and have not licensed or authorized BOSS's BR600. Their marks are used solely to identify the equipment whose sound is simulated by BOSS's BR600. The larger the value set here, the more rapidly compression is applied. Release Time with VtgRack This adjusts the time from when the signal level drops below the threshold until when the compression is. Sens Adjusts the manner in which the enhancer will be applied relative to the input signals. Type Select the mode of the lofi box.

<https://congiendisan.vn/vi/3m-7500-respirator-manual>

Since it suppresses the noise in synchronization with the envelope of the sound the way in which the sound decays over time, it has very little effect on the sound, and does not harm the natural character of the sound. Type This sets the type of the preamp. Speaker Simulator This simulates the characteristics of various types of speakers. When the output of the BR600 is connected directly to a mixer, etc., this can be used to create the sound of your favorite speakers system. Touch wah creates an automatic wah by changing the filter in response to the volume of the input. Pedal wah lets you use an Expression pedal or the like to obtain realtime control of the wah effect. At this time, raise the volume as high as possible without allowing the sound to distort. If you wish to save the effect settings that you edited, save them as a user patch or song patch. Freq This sets the frequency containing popping or other undesirable lowrange noises that you want to cut. Enhancer This adds more liveliness to the sound, putting sounds at the forefront. Lo Thres This sets the volume level at which the lowrange compressor goes into effect. FX Type This sets the type of the effect. CHORUS A sound with a subtly shifted pitch is added to the direct sound, making the final output sound thicker and broader. DELAY This creates a thicker sound by applying a delayed sound to the direct sound. This sets the center frequency 40Hz to 1.5 kHz for the low range equalizer shelving type. And on memory cards, you can store five "Song Patches," which are patches that can be used on an individual song basis. Using this feature, we will be able to correct pitches in real time and in semitone units. The BR600 will stop playback. In certain cases, this will reduce the number of incorrect detections. In actual practice, however, there may be situations where you want to correct only a certain section or adjust the pitch differently.

<http://familymn.com/images/cardo-systems-scala-rider-manual.pdf>

Smth Smooth The value set here is added to the value for the "Smooth" patch parameter p. 127. When set to 0, the correction proceeds at the rate set in the patch's "Smooth". The BR600 features nine preprogrammed collections of drum sounds designed for use in different musical genres drum kits; select the drum kit suited to the type of music you are playing. Arrangement Mode This mode is used for performing arrangements. The patterns are switched during the song according to the order in which they are arranged. The BR600 is programmed with nine internal "preset drum kits." Also included are five original "song drum kits.". Start Point "S" Specify the measure or location to be used as the start point for loading the drum sounds. This is convenient when, for example, you cannot find just the pattern you want from the preset patterns. There are three ways to create patterns. The BR600 is put into Rehearsal mode. fig.04360 Tap the drum pads to practice the performance. The drum sounds are played but not recorded to the pattern. This is convenient for inputting patterns that are difficult to perform using the drum pads. If more than one drum sound is present in the same cell, this is indicated by ". You can use the following procedure to delete drum sounds. The Pattern Edit screen appears in the display. The Pattern Edit screen appears in the display. With the BR600, you can arrange sequences of up to 50 steps. Now try actually creating an arrangement. Starting Measure This sets the measure from which the performance of the pattern selected for the current step is to start. The Preset Arrangement names are permanently assigned when the BR600 is shipped; these names cannot be changed. Step 1 cannot be erased, but instead remains with the step set to "Metro" Metronome. Connect your computer and the BR600 with a USB Task Tray cable. Quit the connection to the computer. Connect your computer and the BR600 with a USB cable. Connect your computer and the BR600 with a USB cable.

<http://ferramentafranza.com/images/cardo-teamset-manual.pdf>

For this reason, the BR600 imports only the data extracted from MIDI Channel 10. Note that data assigned to other channels is disregarded. At this point, you can safely disconnect the USB cable Task Tray from the BR600 and the computer. With Windows icon in the task tray, then click the Task

Bar. Connect your computer and the BR600 with a USB cable. Connect your computer and the BR600 with a USB cable. At this point, you can safely disconnect the USB cable from the BR600 and the computer. Connect your computer and the BR600 with a USB cable. For this reason, the BR600 imports only the data extracted from MIDI Channel 10. Note that data assigned to other channels is disregarded. Any files that are retained will use the required amount of memory on the memory card. The lower part will display a tuning guide to indicate the difference between the input sound and the displayed note. This is helpful if you want to practice playing along with the backing instruments. However, the initialization cannot be carried out unless a memory card is inserted in the BR600 and the song protect function is switched off. Initializing the System Settings Follow the procedure below to initialize the system parameters. If this does not resolve the problem, contact a nearby Roland service center or your dealer. Memory card data was damaged If memory card data has been damaged, the following causes are possible. A newly created song provides approximately 2,000 events per song. Solution 1 Turn off the BR600, properly insert the memory card, then turn the BR600 back on. Solution 2 Initialize the card p. 199. Unsupported Card! DECLARATION OF CONFORMITY Compliance Information Statement Model Name BR600 Type of Equipment Digital Recorder Roland Corporation U.S. Responsible Party 5100 S. Eastern Avenue, Los Angeles, CA 900402938.

The manual should be saved and kept No part of this publication may be reproduced in any form The specific meaning of the symbol is the user to the risk of death or severe determined by the design contained within the injury should the unit be used triangle. This way you from your own body before handling the cards. And, thanks to its an onboard stereo microphone, you can. The BR600 uses 32 MB to 1 GB CompactFlash cards with a 3.3 V power supply. For more on supported memory cards CompactFlash for the BR600, refer to "About Memory Cards" separate sheet. The selected button will light. You can song e.g., fast forwarding and rewinding. MASTER fader Performing this same operation again cancels the mute. Controls the overall volume of the BR600. While the sound is muted, the REC TRACK button for the "Listening to a Demo Song" p. 32 track flashes orange or green. This slot is where memory cards CompactFlash are If the screen is difficult to view, see "Adjusting the Display inserted when you want to save data. This is the power switch. When making any connections, make sure that all devices are turned off. fig.00110 Front Panel Electric Guitar Stereo Headphone Electric Bass Rear Panel AC Adaptor PSA series CD Player etc. Computer Foot Switch FS5U etc. The facing upward. following describes how to connect the mic using this cable. When the power is first turned on, the demo song is automatically selected, and the data required for playback is loaded. This meter indicates the level for each track. Below is an explanation of the operations related to the insert effects. Their settings The BR600 is set to output sound without the insert can be changed, but you cannot create a new preset effects applied, allowing you to record sounds without patch. If a mic is connected either to the MIC1 or MIC2 jack not If the button flashes in red, that track is ready for both, the input will be mono, and you can select tracks recording. The Rhythm cannot be used in this mode.

[www.insurancedirectcanada.ca/wp-content/plugins/formcraft/file-upload/server/content/files/1626ec099bf303---bosch-maxx-washing-machine-service-manual.pdf](http://www.insurancedirectcanada.ca/wp-content/plugins/formcraft/file-upload/server/content/files/1626ec099bf303---bosch-maxx-washing-machine-service-manual.pdf)

Use whichever mode is suitable in the course of bringing your song to completion. The BR600 features eight audio tracks that can be used The BR600 will now enter Input mode. The REC TRACK button will change to blinking in orange or green, and the sound of that track will be muted silenced. The BR600 features chorus, delay, and doubling any one These are just like the tone control on a stereo. This enables you to select the combination of audio quality and recording time that is most suitable for the material you are recording. If a mic is connected either to the MIC1 or MIC2 jack not If the button flashes in red, that track is ready for both, the input will be mono, and you can select tracks recording. You can select any one of being input pan, use the following procedure. Repeating



playback allows you to If you want to save the registration for this repeating check the mixing balance or perform loop recordings p. 63 segment, save the song. Same Location Loop Recording fig.01180 The repeat function p. 58 allows you to play a certain portion of a song the loop portion over and over again. First, insert the memory card containing the copy of the desired data into the BR600. This function is quite useful during editing. Registering a Locator Point At the Play screen, move to the location where you want to register the locator point. Track Copy allows you to copy a specific part of data and then place it in a different location. Track Move allows you to move a specific portion of data to fig.02370 a different location. After the data is moved, the location it was in will be left empty. Even if data exists after the specified part, it will not be moved forward to fill the gap left by the erasure. Like a normal tape recorder, erasing can be considered covering unwanted data by recording emptiness. The display will ask "Are you sure," so that you can Perform the procedure given below to exchange the data confirm the operation. The Song Protect screen appears in the display.

These are grouped according to different input sources and each group is called a "bank." fig.03010. The algorithms that can be selected will differ for each bank. To select the algorithm that you wish to use, first select the effect bank that includes that algorithm, and then refer to the "Effect Patch List". Obtain the sound of a This is a multieffect designed for acoustic guitar. Even bass guitar while playing an electric guitar. This features This is a multieffect designed for bass guitar. COSM COMP VCL This is a multieffect designed for vocals. For the guitar, you can make the electric guitar sound like For the guitar, you can produce an amp sound using a an acoustic guitar. Those companies are not affiliated with BOSS and have not licensed or authorized BOSS's BR600. Their marks are used solely to identify the equipment whose sound is simulated by BOSS's BR600. You can use the following procedure to delete drum sounds. You cannot erase the preset patterns. The Pattern Edit screen appears in the display. With the BR600, you can arrange sequences of up to 50 steps. The current step. content of the following steps are brought forward to fill the erased step. Step 1 cannot be erased, but instead remains with the step set to "Metro" Metronome. You cannot erase the preset arrangements. ROLAND Folder The structure of the files and folders on the BR600 is as follows. Realtime audio signals and MIDI messages cannot be handled via the BR600's USB connector. BR0 Folder. With Windows XP Connect your computer and the BR600 with a USB cable. When the BR600 performs Recover, the data on fig.05080 memory cards will be overwritten. At this point, you can safely disconnect the USB cable from the BR600 and the computer. Quit the connection to the computer. Note that data The names of the SMFs on the memory card are assigned to other channels is disregarded. At this point, you can safely disconnect the USB cable fig.05080 from the BR600 and the computer.

Connect your computer and the BR600 with a USB cable. Back up the data on the card see p. 178. Copy the WAV or AIFF files you want to import. Connect your computer and the BR600 with a USB cable. For this reason, the BR600 imports only the data extracted from MIDI Channel 10. Note that data assigned to other channels is disregarded. As an example here, we will explain how to use the tuner to When the builtin tuner of the BR600 is used, the reference tune your guitar. However, the initialization cannot be carried out unless a memory card is inserted in the BR600 and the song protect function is switched off. Cannot Edit! Quantize is Low! Solution 1 Turn off the BR600, properly insert the Cause During Step Recording of a pattern, the memory card, then turn the BR600 back. The smallest unit of memory used by the BR600 to Cause The memory card has been removed store recorded results on a memory card is the event. A. Solution 1 Turn off the BR600, properly insert the Solution In case of using PSA adaptor memory card, then turn the BR600BR Cable might be broken or adaptor itself 600 back on. For the USA DECLARATION OF CONFORMITY Compliance Information Statement Model Name BR600 Type of Equipment Digital Recorder Roland Corporation U.S. Responsible Party 5100 S. Eastern Avenue, Los Angeles, CA 900402938. Additionally, in order to feel assured that you have gained a good grasp of every feature provided by

your new unit, Owner's manual should be read in its entirety. The manual should be saved and kept on hand as a convenient reference. No part of this publication may be reproduced in any form without the written permission of BOSS CORPORATION. MIC1 This jack allow a mic to be connected. This is TRS type microphone input connector. The BR600 uses 32 MB to 1 GB CompactFlash cards with a 3.3 V power supply. For more on supported memory cards CompactFlash for the BR600, refer to "About Memory Cards" separate sheet.

MIC1 dial This dial adjusts the sensitivity for MIC1 and the onboard stereo mic. The selected button will light. When making any connections, make sure that all devices are turned off. fig.00110 Front Panel Rear Panel CD Player etc. Foot Switch FS5U etc. Electric Guitar or Electric Bass Audio Set etc. Preset patches P The preset patches contain preset data. Their settings can be changed, but you cannot create a new preset patch. If the button flashes in red, that track is ready for recording. fig.00480 The status of each track can be determined from the indicator on the button. Off No recorded data exists on the track. Green Recorded data exists on the track. Use whichever mode is suitable in the course of bringing your song to completion. fig.00520 INPUT Only the instrument sounds or other input sources are recorded to the tracks. Sounds played back from other tracks are not recorded. Use the TRACK faders to adjust the volume separately for each track. If the button flashes in red, that track is ready for recording. fig.00480 The status of each track can be determined from the indicator on the button. Off No recorded data exists on the track. Green Recorded data exists on track. You can select any one of these VTracks for recording or playback. This may make it difficult for you to set the repeat portion exactly as you desire. To enable you to find these points accurately, the BR600 is equipped with the Scrub function. Track Copy allows you to copy a specific part of data and then place it in a different location. In some cases, this unwanted data may occupy a significant amount of space on the memory card. An insert effects, loop effects, and Track EQ can be used simultaneously, and you can make settings for each effect as desired. The reason for this is to allow for the effects processed wet sound to be recorded and monitored. However, sometimes you want to change the connection order. The algorithms that can be selected will differ for each bank.

The larger the value set here, the more rapidly compression is applied. Type Select the mode of the lofi box. Since it suppresses the noise in synchronization with the envelope of the sound the way in which the sound decays over time, it has very little effect on the sound, and does not harm the natural character of the sound. Type This sets the type of the preamp. The sound will be unmusical and lack distinctive pitches. Touch wah creates an automatic wah by changing the filter in response to the volume of the input. The overall volume is adjusted by the MASTER fader. FX Type This sets the type of the effect. CHORUS A sound with a subtly shifted pitch is added to the direct sound, making the final output sound thicker and broader. When compared with guitars, pianos, and other musical instruments, the human voice generally produces a relatively unstable tone. The solo part will be played and any incorrect pitches will be fixed. The BR600 features nine preprogrammed collections of drum sounds designed for use in different musical genres drum kits; select the drum kit suited to the type of music you are playing. There are three ways to load drum tones. Loading from the tracks. This is convenient when, for example, you cannot find just the pattern you want from the preset patterns. There are three ways to create patterns. You can use the following procedure to delete drum sounds. You can then save these arranged patterns as song arrangements. You can create song arrangements of up to 999 measures. The builtin tuner supports both guitar and bass guitar. Patch Name Algorithm 01 JC Clean COSM GTR AMP 02 HiGainLd COSM GTR AMP 03 Over Drv COSM GTR AMP 04 Phased COSM GTR AMP 05 Crunch COSM GTR AMP 06 MS Strgt COSM GTR AMP 07 St WACK COSM GTR AMP 08 Ambient COSM GTR AMP 09 Voxy. If this does not resolve the problem, contact a nearby Roland service center or your dealer. Memory card data was damaged If memory card data has been damaged, the following causes are possible.

Refer to this list and take the appropriate action. Battery Low! Cause The batteries are depleted 6 x AA Alkaline dry cell batteries. Cause There are no songs on the memory card. Solution Create a new song p. 54. Cause Incorrect data is in the song folder, or the necessary data is not present. Solution Restore the data backed up on the computer to the BR600. Data Type HiFi MT2 STANDARD LV1 LONG LV2. For EU Countries For Canada This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations. Used Very Good Serial No xxx8641 Please refer to all photos for reference of condition. Note No box or manual. Something we hope you'll especially enjoy FBA items qualify for FREE Shipping and Amazon Prime. Learn more about the program. Please try again. Please try again. In order to navigate out of this carousel please use your heading shortcut key to navigate to the next or previous heading. Register a free business account Please try your search again later. Amazon calculates a product's star ratings based on a machine learned model instead of a raw data average. The model takes into account factors including the age of a rating, whether the ratings are from verified purchasers, and factors that establish reviewer trustworthiness. Please try again later. Michael 1.0 out of 5 stars So complicated, could hardly do ANYTHING with it. Did not come with users guide or an AC adapter. Not worth the money, not to mention, one of the channels didn't even work and another was all static when using the volume controls. The box is fairly small and turns out some really nice sounding production professional quality to my admittedly hobbist ears. The upside is that the system is fairly easy to use it gets easier with practice and there are no recording artifacts like white noise, tape noise, etc. Onboard effects for guitar and bass guitar are great. There are a few downsides, however.

The biggest is that this is a complex system that takes a lot of time to master. You can do simple songs within a couple of hours of opening the box, but there are so many features that the average Joe will never learn them all. I don't think I've used more than 10% of the system's capability yet. The other downside are the drum tracks. While there are many of them, and there is a cool way to layout drum arrangements for songs, none of the tracks really seem to suit my needs basic rock and roll and basic jam band styles. In theory you can create your own drum patterns with the touch sensitive buttons, but I haven't yet figured out how to do this well. Seems like you need two VERY talented and agile fingers to make a useful pattern. But all of these are fairly minor gripes if you aren't looking to be a Grammy winning artiste quite yet. Overall the system does all that I need it to do record four to eight track songs, add effects, mix, and then transfer to my computer. I transfer the songs in .aiff format to iTunes and then either play them through my iPod on my home stereo system, burn them to CD, or convert them to MP3 to share with friends. All of my friends think the recordings were done professionally! There is a lot of glitches with its built in firmware, but when you learn to overcome them, you can get a very professional product from this machine. One balanced adapter is included. 64 virtual tracks allow you to record 8 tracks then bounce a mix onto two virtual tracks and then record even more tracks while listening to the mix you've already recorded. You can continue to add tracks this way until all 64 virtual tracks are full. The great thing is that, as long as you don't record over your original recordings then you can still remix everything either in the machine or by dumping all of the tracks to your computer and mixing it there. You can record your tracks dry no effects but still hear the effects while you record.

<http://ninethreefox.com/?q=node/10433>