



**File Name:** casablanca fans stealth manual.pdf

**Size:** 2390 KB

**Type:** PDF, ePub, eBook

**Category:** Book

**Uploaded:** 13 May 2019, 21:35 PM

**Rating:** 4.6/5 from 623 votes.

**Status:** AVAILABLE

Last checked: 19 Minutes ago!

**In order to read or download casablanca fans stealth manual ebook, you need to create a FREE account.**

**[Download Now!](#)**

eBook includes PDF, ePub and Kindle version

[❑ Register a free 1 month Trial Account.](#)

[❑ Download as many books as you like \(Personal use\)](#)

[❑ Cancel the membership at any time if not satisfied.](#)

[❑ Join Over 80000 Happy Readers](#)

### **Book Descriptions:**

We have made it easy for you to find a PDF Ebooks without any digging. And by having access to our ebooks online or by storing it on your computer, you have convenient answers with casablanca fans stealth manual . To get started finding casablanca fans stealth manual , you are right to find our website which has a comprehensive collection of manuals listed.

Our library is the biggest of these that have literally hundreds of thousands of different products represented.



## Book Descriptions:

# casablanca fans stealth manual

You can use the search box to the right to quickly find the fan you're interested in. From our troubleshooting guides to our over 1000 PDF user manuals, we have it all. Always turn Retain this manual for future reference. All wiring must be performed in accordance with national and local electrical codes. If you are To avoid overheating and possible damage to other equip The outlet box must be UL Listed for ceiling fan installations, Casablanca extension poles are available for sloped or high ceiling installations. The maximum current require Maximum light current is 2.8 amps or 340 When installing the canopy hatch, make sure all wires. Always turn the power OFF to the ceiling fan before servicing it, working on it, or replacing light bulbs. Contact Casablanca Fan Company by calling toll free 18882272178, or contact your local authorized Casablanca dealer for assistance in obtaining service. READ AND SAVE THESE INSTRUCTIONS SAFE USE Safety and the proper operation of your Casablanca fan both require a thorough knowledge of the product and proper installation; therefore, before attempting to install and operate your Casablanca fan, read this owner's manual completely and carefully. Retain this manual for future reference. SAFETY FIRST BEFORE YOU START PN 3243Z HN1209 CAUTION To avoid possible electrical shock, make certain that electricity is turned off at the circuit breaker or fuse box before attempting any installation procedure. All wiring must be performed in accordance with national and local electrical codes. If you are unfamiliar with the wiring codes, you should use a qualified electrician. The outlet box must be UL Listed for ceiling fan installations, if it is not, a new box must be installed. Casablanca extension poles are available for sloped or high ceiling installations. The maximum current requirement for the fan with light fixture is 2 amps. The fan uses about 1 amp or 100 watts. Maximum light current is 1.0 amps or 100 watts of lighting.<http://appfreshy.com/boulter-economy-boiler-manual.xml>

- **casablanca fan stealth manual, casablanca stealth fan instructions, 1.0, casablanca fan stealth manual, casablanca stealth fan instructions.**

When installing the canopy hatch, make sure all wires are within the canopy and that no wires are being pinched. For best performance and for your warranty to be valid, use only genuine Casablanca blades, light fixtures, and accessories. Before mounting your Casablanca fan, read the following helpful recommendations. The location of the fan, airPage 4 CEILING HARDWAREPage 6 attaching the blades. Step 3a. Attach the 5 blade tips to the blades using two 3a BLADE TIP. Step 6. Tuck the wires into the canopy with the wire nutsWALL CONTROL AND Hardware not to scaleAlways turn the power off. CAUTION To avoid possible electrical shock, make certain that electricity is turned offTo avoid overheating and possible damage to other equipment, do not install control to a receptacle, fluorescent light fixture, motor operated appliance,The outlet box must be UL Listed for ceiling fanCasablanca extension poles are available for sloped or high ceilingThe maximumThe fan uses about 1 amp or 100 watts. Maximum light currentWhen installing the canopy hatch, makeFor best performance and for your warranty to be valid,Always turnThe location of the fan, airLocation. Ceiling fans have practical uses in almost every room in your home. We suggest you follow theseHigh humidity combinedFan Size. Variable fan speed capability permits the use of a fullsize 52.Ceiling HeightStandard. StandardFor best performance and best appearance, an extension pole should beCasablanca Dealer for details. Note Fan may wobble or vibrateUse the tearoff Ceiling Angle Template card insertedIt is OK to install your fan.PoleYour fan will not hang straight down,Contact yourAdaptor."Before discarding packaging material, be certain that all parts haveFan preparationPrepare for fan installation as follows. Step A. Route the wires from the motor through

the. Tip The downrod has a taperedStep B. Using the provided allen wrench, loosen the setThread the downrod into the motor coupling until it stopsStep

C.<http://eg-steel.com/userfiles/boulter-economy-manual.xml>

Securely tighten the set screw with the providedCAUTION Failure to fully lock in the downrodIf not, a 2" x 4" stud mustStep 2.Route the outlet box wires through the keyholeCAUTION To reduce the risk of personalTighten until outletThis box must be firmlyWe recommend that the ceilingStep 4. Attach the canopy to the crossbar mounting bracket with threeHand tighten until snug against the ceiling. Note On sloped ceilings, align theStep 3a. Attach the 5 blade tips to the blades using two 3a BLADE TIP installationNote the screwsStep 3b. Attach each of the five blades to the bladeThe truss head screwHand tighten eachStep 4. To hang the fan body in the canopy, support theRotate the fanNote Write down the. Serial Number andStep 5. Attach the fan wires to the ceiling fixture outletConnect in this order. GROUND conductor of power source. Secure withSecure with wire nut.Step 6. Tuck the wires into the canopy with the wire nutsStep 7. Install canopy hatch with the last canopy screwTip Place the lock washer on the canopyStep 8. Straighten the fan, then check to ensure thatStep 9. Screw the 100watt Halogen bulb into the socket. If it is touched,A dirty glass bulbIMPORTANT! When installing the halogen bulb,NOTE In compliance with US Federal Energy. Regulations, this ceiling fan contains a deviceStep 10. Position the indentations inStep 11. Carefully lift the glass shadeStep 12. Rotate the glass shade in aStep 13. Turn power back ON at theThis completes the installation of theIndentationWALL CONTROL AND Hardware not to scaleWall Control. Screws 2. Switch BezelsWhite Wall. Plate1. Almond Wall. Wall Plate. ScrewsWarning! To avoid possible electrical shock, make certain that electricity is turned off at the circuitIf you are going to use white, skip these steps and goStep 17a. Locate the four 4 tabs holding the bezel toThe wall control installs in the same manner as an ordinary light switch, using an existing wall box and wiring.

ThisSingle W85 InstallationW85 is used to describe either white 11 or almond finish. If you have multiple InteliTouch 3 fans, refer to the sectionSTRIP wire on the W85 wall control. Secure this connectionNOTE The RED wire is not used in thisTo control the fan and lights from two locations a threeway circuit, use two W85Then make sure that the dip switchesIf you are installing otherW85 wall controls.Connect the blackSecure the splice with aW85. Secure the splice with a wire nut.Secure the splice with a wire nut.Repeat steps 1 through 9.TheAlways turn the power offTheOperation Speed Control. There are six individual speed settings for the fan; each speed is indicatedFan Control. To select the desired fan speedThe fan speed is now in memory and will automatically come on at theWhen the fan is on, you mayChange speed. Press and hold. FAN button longerOperation Reversing Airflow. The direction of airflow can be changed from downward to upward or from upward to downward. To reverse the airflowNote A fourtoned signalOperation lights. To turn the lights off and on, press and release theTo vary the light brightness at each touch level. To vary the light brightnessAfter one second the lights willNOTE Light Operation the light varies from "bright" to "dim" overThis sequence will reverse the light when it reachesRelease the button when the desired level is reached.The brightness level is now in the fan memory and will automatically come on atChange brightness. LIGHT button longer than oneNOTE All fans leave the factory set toStep 1. Turn power OFF at the circuit breaker or fuse box and at the toggle switch,NOTE DO NOT set dip switch setting in the remoteStep 2. Remove the screws and switch plate from the existing switch box. Step 3. Remove the screws holding the switch in the switch box. Step 4. Pull the existing W85 switch from the switch box to expose the dip switches. Step 5. Change the dip switch settings, assuring that they are different from theStep 7.

At the circuit breaker or fuse box and at the toggle switch, turn the power offStep 8. Within 20 seconds of restoring power to the ceiling fan and the W85 Wall. Control press and hold both the "FAN" and "REVERSE" buttons as shown in Figure. Automatic Demonstration ProgramIt can be

used To enter the demonstration program A multitone signal will verify the start of the test program which proceeds as follows The complete cycle lasts slightly over one minute. It The SafeExit Program gives you about thirty seconds of light when you turn the lights off, To enter the SafeExit Program. SafeExit Immediately press the buttons in the following sequence Button after an audio tone The lights will blink to indicate this command has been After thirty NOTE If the lights are left on in the room, the lights will automatically turn. OFF after 2 hours. this is LightMinder. The LightMinder Program automatically turns OFF the fan mounted lights after two To enter the LightMinder Program Once the lights turn on, they will The lights will stay After thirty seconds have elapsed, the lights The HomeSafe Program makes an unoccupied home appear occupied by turning To enter the HomeSafe Program. Button off for a least 5 seconds. Once the lights This seven hour pattern will repeat continuously so that a different pattern of lighting Button OFF for five The program To enter the FanMinder Program OFF for at least 5 seconds. A timer is now initiated and the fan will The fan will not, however, descend below The fan will again reduce one speed for each OFF for three seconds. Please refer to this troubleshooting guide before requesting service or contacting your dealer for assistance. Check all wire connections. Make sure the power is turned off during this Check all connections. Replace the fan receiver. Within 20 seconds from restoring Make sure the hanger bracket is attached tightly to the ceiling outlet box Make sure all Fan wobbles or shakes excessively. Fan is noisy during operation.

Fan does not run on low speed This device complies with RSS210 of Industry Canada. Operation is subject to the following two conditions 1 this device Operation is subject to the following two conditions 1 this device However there is no guarantee If this equipment does cause harmful interference to radio or Note Any changes or modifications to the Model Number 32xxZ. Dimensions. NOTE Dimension B Weight Motor. Blade Span. Blade Iron Pitch. No. of Blades. Technology. Lightbulb Airflow No lighting wattage is included. If more than one fan is being installed, be careful not to mix blades from different cartons. Inspect the contents of your carton for possible shipping or handling damage and report any such damage directly to your authorized Casablanca dealer. It is always a good idea to have an assistant to help with the installation. When cleaning, painting, or working near your fan, be very careful of the fan and blades. Contact Casablanca Fan Company by calling toll free 18882272178, or contact your local authorized Casablanca dealer for assistance in obtaining service. READ AND SAVE THESE INSTRUCTIONS SAFE USE Safety and the proper operation of your Casablanca fan both require a thorough knowledge of the product and proper installation; therefore, before attempting to install and operate your Casablanca fan, read this owner's manual completely and carefully. Retain this manual for future reference. SAFETY FIRST BEFORE YOU START PN 1943650 A T1008 CAUTION To avoid possible electrical shock, make certain that electricity is turned off at the circuit breaker or fuse box before attempting any installation procedure. CAUTION RISK OF ELECTRICAL SHOCK. All wiring must be performed in accordance with national and local electrical codes. Casablanca extension poles are available for sloped or high ceiling installations.

This ceiling fan requires a grounded electrical supply of 120 V AC, 60 Hz and a minimum 15 amp circuit. The maximum current requirement for the fan with light fixture is 3.8 amps. The fan uses about 1 amp or 100 watts. Maximum light current is 2.8 amps or 340 watts of lighting. Where wires are employed, be sure all bare wires are within the connectors. When installing the canopy hatch, make sure all wires are within the canopy and that no wires are being pinched. The location of the fan, air circulation, and fan size are all important factors to consider before installation. Location Ceiling fans have practical uses in almost every room in your home. Before discarding packaging material, be certain that all parts have been removed. If not, a 2" x 4" stud must be installed. Tighten until outlet box is firmly mounted to beam. This box must be firmly secured to the ceiling. We recommend that the ceiling fixture outlet box be of sufficient capacity enabling it to support the weight of fan and light fixture under any conditions. Page 6 attaching the

blades Step 3a. Attach the 5 blade tips to the blades using two 3a BLADE TIP installation 632x18" round head screws provided. Note the screws have 632x18" locktite on them, so once they are installed it will be difficult round head to remove the screws. To do this, tilt the fan body away from the hatch opening. This controller is designed to signal the fan microcomputer as well as perform normal switching operations. Always turn the power off during cleaning or servicing the fan and during thunderstorms. It is also used to exit or enter additional programs. POWER must be left on to retain a previously set fan speed or light level. The fan and light will operate normally using the buttons to turn them on and off. Caring for Finishes For cleaning, a soft brush or lintfree cloth should be used to prevent scratching the finish. A vacuum cleaner brush nozzle can remove heavier dust.

Surface smudges or an accumulation of dirt and dust can easily be removed by using a mild detergent and slightly dampened soft cloth. Save screws for later. Do not use with wall dimmer. Please observe proper polarity placement. Replace Battery Door. The light will automatically turn ON and OFF in a seemingly random manner over an eight and a quarter hour programmed cycle that is designed to give the home a "lived in" look. Regardless of the light setting when switching to the Security mode lights on or off, dim or bright, the lights will increase to high brightness and then begin the Security cycle. Weight 33 lbs. Motor Blade Span Blade Iron Pitch No. Using the online preview, you can quickly view the contents and go to the page where you will find the solution to your problem with Casablanca Fan Company Stealth dc C45GxxxB. To start viewing the user manual Casablanca Fan Company Stealth dc C45GxxxB on full screen, use the button Fullscreen. However, if you do not want to take up too much of your disk space, you can always download it in the future from ManualsBase. The option to print the manual has also been provided, and you can use it by clicking the link above Print the manual. You do not have to print the entire manual Casablanca Fan Company Stealth dc C45GxxxB but the selected pages only. paper. If you want to quickly view the content of pages found on the following pages of the manual, you can use them. Retain this manual for future reference. CAUTION To avoid possible electrical shock, make certain that electricity is turned off at the circuit breaker or fuse box before attemptin Before you begin to assemble and install your Casablanca fan, remove all parts from the carton and check them against the Parts Guide in this manual. Make sure all parts are included in the box using the Parts Guide on the following pages.

If there are missing or broken parts Always turn power to the ceiling fan OFF before Call 18882272178 MondThe location of the fan, air circulation, and fan size are all important factors to consider before installation. Location Ceiling fans have practical uses in almost every room in your home. Ceiling Fan Step 2. Tighten the screws into the outlet box; Approved do not use lubricants on the screws. Do not over Wiring Box tighten. Canopy NOTE On sloped ceilings, align the canopy opening with the top or peak of the room. Canopy Screw Lock Washer HANGING HARDWARE All MOTOR TAPERED COUPLING THREAD Tip The downrod has a tapered thread that MOTOR is designed to lock completely when instTo do this, tilt the fan body away from the hatch opening. Tighten the screws Figure 4. Step 3. Straighten the fan, then check to ensure FIGURE 4. there is no movementA dirty glass bulb will cause the bulb to fail almost immediately. IMPORTANT! When installing the halogen bulb, carefully cut off the end of the plastic sleeve the bulb comes in and hold the bulb by the plastic sleeve to screw it into ON ECE Step 2. Open the battery compartment door of the remote 1 2 3 4 control and remove the battery. Step 3. Change the dip switch settings, assuring that they SET are differEach speed is indicated by the number on the controller. Check all wire connections. Please check your inbox, and if you can't find it, check your spam folder to make sure it didnt end up there. Please also check your spam folder. For details, contact Casablanca at 18882272178 or visit us on the Web at [www.casablancafanco.com](http://www.casablancafanco.com). Do not return your fan without approval from Casablanca Fan Company. Should it become necessary to return your fan to an Authorized Service Center, make sure it is packaged properly to avoid intransit damage, which is not

covered by this warranty. In addition, this warranty does not cover minor variations in plated metal finishes due to the imperfect nature of the plating and finishing process.

Handblown glass may contain blisters, seeds, or thin lines. These characteristics are not defects, but substantiate that this All costs of installing, removing, and reinstalling the product are the responsibility of the owner. Underwarranty motors requiring repair must be shipped to the factory for replacement. Casablanca will pay for No other expressed warranty is given. The repair or replacement of a product is the consumer's exclusive remedy. Most Service Center contracts cover up to a 30mile radius from their place of business. Casablanca will not cover repairs caused by improper installation. After the 120day period, the consumer will be charged for the service call and labor. Casablanca will pay for all defective parts through the duration of the parts warranty. NOTE Service Centers are required to submit a Proof of Purchase with each warranty claim. The consumer must provide a copy of the Proof of Purchase at the time of service. If no inhome service is available, the consumer has the option of sending an inwarranty fan to Casablanca Fan Company in Memphis, TN, for repair. The fan must be packaged properly, shipped freight prepaid, and The fan will be repaired and returned at no charge to the consumer, freight prepaid. September 2008 Call our tollfree Consumer Affairs hotline at 8882272178, Monday through Friday, 8 a.m. to 5 p.m. Central. Retain this manual for future reference. Before you begin to assemble and install your Casablanca fan, remove all parts from the carton and check them against the Parts Guide in this manual. Replacement parts will be sent to you via Federal Express. The blades in each pack are matched for equal weight to assure smooth fan operation. If more Contact your local Authorized Service Center. Our Web site at [www.casablancafanco.com](http://www.casablancafanco.com) contains additional information on Casablanca Please do not return this product to the store. All electrical components must be installed in accordance with national and local electrical codes.

To reduce the risk of fire and electrical shock, use this light fixture only with UL Listed Casablanca Stealth or S3 Ceiling Fan s. FOR AN EXISTING FAN SOCKET PLUG NO LIGHT CAP Step 1. Remove existing glass by gently pushing up on the glass and rotate glass counterclockwise until the glass tabs from the fixture align with the indentations on the glass. Step 2. Remove halogen light bulb from socket. Step 3. Package up glass and bulb for safe keeping if you ever decide to reinstall. Step 4. Install socket plug into the socket. Step 5. Take the No Light Cap and position the indentations in the outer rim of the cap so that they line up with the tabs on the inside surface of the fixture rim Step 6. Carefully push the cap up inside the light fixture as far as it will go and rotate in a clockwise direction until it falls into the notch for each tab. Step 7. Turn power back on at the circuit breaker or fusebox. Thank you, for helping us keep this platform clean. The editors will have a look at it as soon as possible. Page Count 69 Quality in Every Detail. Comprehensive Warranty. Energy Efficient. Malibu Star. Antion. Trident. Vita. Modena II. Star. Starlet Four Seasons III Hugger Alessandria New Orleans Centennial. Vicente Panama DC. Panama Energy Star. Four Seasons III. Four Seasons III Gallery. Concentra Holliston DC. Academy. Academy Gallery. Whitman. Bresica Pullchain. Bresica Control. Bel Air. Bel Air Halo. Colorado. Capistrano. Metropolitan. Veneto Stealth. Stealth DC. Tercera Mission. Marrakesh. La Fleur. Key Largo II Heritage. Charthouse. Atria. Wailea. Lanai. Four Seasons III Outsider. Estrada. Continental. Utopian Light Fixtures and Glass. Controls.

Hanging System Reference Charts Alphabetical Casablanca's latest introductions include a variety of new ceiling fan collections in an array of timeless styles that Every detail is given meticulous attention—from design to components and manufacturing to ease of installation Casablanca's These motors deliver exceptional Strikes the perfect balance between Designed and engineered for specific Casablanca offers prepaid freight to make it easy for you to send the fan to the Casablanca Factory Service Center It will be Casablanca's Comprehensive Warranty, the most extensive in the ceiling fan industry, also includes With this extensive coverage, you can enjoy the beauty, quality, and performance of your. Casablanca products for decades to come. ENERGY STAR logo throughout

this catalog Specific fan models are equipped with highly efficient compact For your convenience, we've include this informational energy chart on every ceiling fan page. Airflow. X,XXX cfm. Electricity Use. XX w. Airflow Efficiency Candelier Dark Walnut blades. Add the warm, intimate ambience of candlelight to a spacious room with the Candelier II ceiling fan. The fixture's ingenious design features W75DL optional. Fourspeed wall control with Independent uplight and Fourspeed remote control Independent uplight and Electricity Use BB21WD Dark Walnut blades. K164A4 fitter with G911 Teck Antique side glass Reclaimed Antique blades B103 Walnut blades. The Victorian series marries classic turn of the century appeal with contemporary The richness of the ornate design is enhanced with badgestyle blade holders. Optimum performance is. With a rich finish and exquisite detailing that echo the medallions and paneling of neoclassical architecture, the Alessandria ceiling fan is a The fan's carved featherwood blades and fully dimmable lighting with Scavo glass add Old World warmth, W65 optional. Sixspeed wall control with Sixspeed remote control with. LCD display screen, fullrange Includes wall plate bracket. W505 included.

Threespeed handheld remote with fullrange light dimming, Electricity Use Mahogany blades and optional Shown without Four Light CFL Fixture Available finishes. Burnished Brass 69. In the electric era of the 1800s, fans were characterized by spiral ceiling rods and centrally placed blade holders. The 19th Century fan The intricate, ornate patterns recall decorative W65 optional. LCD display screen, fullrange Includes wall plate bracket. B522 Antique Oak blades. Northern Sienna motor Shown without decorative But it's the fan's performance that The New Orleans Centennial is a faithful replica of a 100yearold ceiling fan discovered in the French Quarter of New Orleans. The elaborate cast motor housing and lacy, scroll brackets recreate the wonderful ambience of a Southern parlor in a time gone by. Pullchain DW52 optional. Threespeed remote control Includes wall plate bracket. W74DL included. W75DL optional. Fourspeed wall control with Independent uplight and Fourspeed remote control Independent uplight and Electricity Use Espresso blades. Onyx Bengal motor with reversible Cottage White blades. Brushed Cocoa motor. Distressed Walnut blades. Cottage White motor with. Cottage White blades and. Snowflake Linen glass. Basque Black motor with. Espresso blades and. Champagne Scavo glass Painstakingly meticulous columns grace the motor housing to create a sophisticated, timeless look. A quality great New Universal Control System The perfect complement to any room. Comes with remote control. Electricity Use New Universal Control New Universal Remote Fourspeed wall control Fourspeed remote control Electricity Use Espresso blades. Cottage White blades Basque Black motor with. Champagne Scavo glass New Universal Control System Fourspeed remote control and New light kits coming in 2013 Complete with our ornate threelight fixture—one of Casablanca's finest. Electricity Use B202 Mahogany blades. Snow White motor Matte Snow White blades. Bright Brass motor Walnut blades. Weathered Copper motor Relic blades.

Antique Brass motor Walnut blades. The first fivebladed fan in the industry, the Panama is an American classic. The traditional styling works with virtually any setting. It's also one of the quietest ceiling fans available. Custom design your Panama by adding your choice of blades, light fixtures and Walnut blades. Architectural White Architectural White blades. Oil Rubbed Bronze motor Dark Cherry blades. Matte Black motor Matte Black blades Pullchain G Includes wall plate bracket. W85 included. W65 optional. LCD display screen, fullrange Includes wall plate bracket. Electricity Use Airflow Efficiency. Classic White motor Classic White blades. Brushed Cocoa motor Dark Walnut blades. Airflow Electricity Use Airflow Efficiency B561 Matte Snow White blades. Brushed Cocoa motor with reversible Matte Snow White blades. Brushed Nickel motor. Burnt Walnut blades. Brushed Cocoa motor Walnut blades. Brushed Nickel motor Dark Walnut blades. A new spin on the original fivebladed fan, the Panama DC features a larger, 54inch span and our extremely powerful DC motor. A new, true classic. It moves air up to 20 percent more efficiently, which helps you conserve energy, save money and protect the environment. Think that feels Sixspeed control with fullrange light dimming and reversing. W75SL optional. Fourspeed wall control with Fourspeed

remote controlElectricity UseSnow White motor with. Bleached Oak blades. OilRubbed Bronze motor. Antique Oak blades. Antique Brass motor with. Casablanca quality, excellent value, and luxury of finish and control choice make the Four Seasons III the best ceiling fan in its class. Traditional in styling, this versatile fan offers selection and features worthy of the Casablanca name. Classic White motor with. Bleached Oak bladesPullchain DThreespeed remote controlIncludes wall plate bracket.Threespeed remote controlElectricity Use. Airflow Efficiency. Airflow EfficiencyArchitectural White motorAirflow.

Note Must use accessory control to operate accessory light fixtures without a pullchain.Matte Snow White bladesMahogany blades. With its integrated bowl light fixture, the valueadded Four Seasons III Gallery fan brings illumination as well as comfort to interior settings. Reversible blades double your decorative options.Pullchain DThreespeed remote controlIncludes wall plate bracket.Brushed Cocoa motor shownB204 Architectural. White bladesCasablanca's hallmark of quality and performance continues with this fan. The Concentra features a fresh design wellsuited for bothPullchain DIncludes wall plate bracket.Dark Cherry blades. K2AA fitterReclaimed Antique blades, shownSnow White blades, shown with. K4SA11 fourlight fitter and. G917 White Satin side glassAntique Pewter motor with. Dark Walnut bladesW84 included. W64 optional. LCD display screen, fullrangeIndependent uplight andEspresso bladesChrome motor with reversibleMatte Snow. White blades. Brushed NickelOilRubbed BronzeIdeal for large rooms, our new DC motor makes it one ofSo you conserve energy, save money and help protect the environment—stayingThe smartlooking Academy teaches an important lesson in design flexibility. Its transitional styling combined with a wide selection ofSixspeed control with fullrange light dimming and reversing.Includes wall plate bracket.Pullchain KElectricity UseOilRubbed Bronze motor withSnow White blades. Talk about your overachievers. The Academy Gallery takes honors for best allaround with transitional styling, a wide selection of finishPullchain KW52 optionalIncludes wall plate bracket. Electricity UseDark Cherry bladesRosewood bladesReclaimed Antique blades.