



File Name: casio electronic cash register pcr-t280 manual.pdf

Size: 4310 KB

Type: PDF, ePub, eBook

Category: Book

Uploaded: 13 May 2019, 19:34 PM

Rating: 4.6/5 from 692 votes.

Status: AVAILABLE

Last checked: 4 Minutes ago!

In order to read or download casio electronic cash register pcr-t280 manual ebook, you need to create a FREE account.

[Download Now!](#)

eBook includes PDF, ePub and Kindle version

[Register a free 1 month Trial Account.](#)

[Download as many books as you like \(Personal use\)](#)

[Cancel the membership at any time if not satisfied.](#)

[Join Over 80000 Happy Readers](#)

Book Descriptions:

We have made it easy for you to find a PDF Ebooks without any digging. And by having access to our ebooks online or by storing it on your computer, you have convenient answers with casio electronic cash register pcr-t280 manual . To get started finding casio electronic cash register pcr-t280 manual , you are right to find our website which has a comprehensive collection of manuals listed. Our library is the biggest of these that have literally hundreds of thousands of different products represented.



Book Descriptions:

casio electronic cash register pcr-t280 manual

Simple to use! 20 departments and 1200 PLUs Automatic Tax Calculations Calculator function Users Manual PCRT280 Electronic Cash Register CASIO COMPUTER CO., LTD. 62, Honmachi 1chome Shibuyaku, Tokyo 1518543, Japan CI Canada Next Users ManualSafety precautions. Page 4 INTRODUCTIONPage 7 GETTING TO KNOW YOUR CASH REGISTER. Keyboard. Page 8 Daily Job FlowPage 10 Part1 QUICK START OPERATIONPage 11 Part1 QUICK START OPERATIONWhenever an. Page 14 Part1 QUICK START OPERATIONPage 17 Part1 QUICK START OPERATIONExampleTo. Page 24 Part2 CONVENIENT OPERATIONPage 29 Part2 CONVENIENT OPERATIONYou can enter "A" byPage 37 Part2 CONVENIENT OPERATIONPage 42 Part3 CALCULATOR FUNCTIONPage 44 Part4 USEFUL INFORMATION. Simple to use! 20 departments and 1200 PLUs Automatic Tax Calculations Calculator function Users Manual PCRT280 Electronic Cash Register CASIO COMPUTER CO., LTD. 62, Honmachi 1chome Shibuyaku, Tokyo 1518543, Japan CI Canada 1 2 3. 46 Summary of content 46 pages Page 1 PCRT280 Electronic Cash Register Users Manual STARTUP is QUICK and EASY. Simple to use! 20 departments and 1200 PLUs Automatic Tax Calculations Calculator function CASIO COMPUTER CO., LTD. Page 2 INTRODUCTION Thank you very much for purchasing this CASIO electronic cash register. STARTUP is QUICK and EASY. Part1 of this Users Manual can help you make a quick start. After reading this guide, keep it close at hand for easy reference. Page 4 INTRODUCTION Warning. Use a dry cloth to periodically wipe off any dust built up on the prongs of the plug. Humidity can cause poor insulation and create the danger of electric shock and fire if dust stays on the prongs. Do not allow the power cord or plug to become damaged, and never try to modify them in any way. Continued use of a damaged power cord can cause deterioration of the insulation, exposure of internal wiring, and short circuit, which creates the danger of electric shock and fire. Page 5 Contents Getting to know your cash register. Daily Job Flow.<http://aquafilling.com/userfiles/bushmaster-jupiter-f900-manual.xml>

- **casio electronic cash register pcr-t280 manual, casio electronic cash register pcr-t280 manual, casio electronic cash register pcr-t280 manual pdf, casio electronic cash register pcr-t280 manual form, casio electronic cash register pcr-t280 manual online, casio electronic cash register pcr-t280 manuals, casio electronic cash register pcr-t280 manual free, casio electronic cash register pcr-t280 manual instructions, casio electronic cash register pcr-t280 manual downloads, casio electronic cash register pcr-t280 manual software.**

6 8 Part1 QUICK START OPERATION. 9 Loading Memory Protection Battery. Loading Paper Roll. Page 6 GETTING TO KNOW YOUR CASH REGISTER Getting to know your cash register Mode Switch REG CAL X OFF RF OP OP key The position of the Mode Switch controls the type of operations you can perform on the cash register. The PROGRAM key marked PGM can be select any Mode Switch setting, while OPERATOR key marked OP can be used to select OFF, REG or CAL only. Z PGM RF OFF REG CAL X Z OP key PGM key PGM PGM OFF In this position, the power of the cash register is off. Enough small change in er. Page 10 Part1 QUICK START OPERATION 3. Setting the Cash Register. Open the platen arm.Page 13 Part1 QUICK START OPERATION 9. Basic Operation after Basic Programming Mode Switch REG Note Whenever an error is generated, the input figures reset to 0. All printout samples are journal images and the header date, time and consecutive no. are eliminated from the samples. Bh Quantity Multiplication X Unit price 3. Entered 150 for unit price by mistake instead of 105. Registered Department 2 Z h Quantity Multiplication ZB. Page 16 Part1 QUICK START OPERATION 10. Daily Management Report This section tells you the procedures to

use to produce reports of the transaction data stored in the cash registers memory. Important Remember that when you issue a reset Z report, the data that is reported is cleared from the applicable totalizers. To view data without clearing totalizers, issue a read X report. Page 17 Part1 QUICK START OPERATION No.Minus department Z No limitation for manually entered price.7digits Maximum number of digits for manually entered price. Page 21 Part2 CONVENIENT OPERATION 17 General features 171 To set general controls C P3 appears in mode display NXX Program code No. Select a number from list A p o To end the setting Select a number from list B Select a number from list C Select a number from list D Selections Yes No. V Time displays with second.<http://gallery4walls.com/upload/editor/bushmaster-jupiter-f700-telescope-manual.xml>

Allow split cash amount tendered. Allow split check amount tendered. A Part2 Key catch tone. Page 22 Part2 CONVENIENT OPERATION 172 To set printing controls Mode Switch C REG BXX RF PGM Program code No. p Always "0" Select a number from list B To end the setting Select a number from list C Selections Print the time on the receipt and journal. Page 23 Part2 CONVENIENT OPERATION 174 Printer switch for Receipt or Journal The printer is initialized as receipt. Z Example To print a journal. Z Selections Print receipt with single height. ZX Zp Z Page 24 Part2 CONVENIENT OPERATION 182 Unit Prices for PLUs Example PLU No. Z p Unit Price Xi PLU No. C P3 appears in mode display CXN Program set code No. Page 25 Part2 CONVENIENT OPERATION 110 To program Tax Table Mode Switch REG 1101 Canadian Tax Table CAL X Z OFF Type 1 Choose the tax rate from a preset tax table for British Columbia, Manitoba, Ontario, Prince Edward Island, Quebec and Saskatchewan. Page 27 Part2 CONVENIENT OPERATION 22. Reset department name. Department Name Character code 2 DEPT01 0 X P2 appears in mode display To end the setting 23. Programming department PLU 2 CLOTHING 402 30 UMBRELLA 403 Part2 PLU11200 Name Character code X P2 appears in mode display XizVXp CizVCp To end the setting 24. Reset PLU name. Page 28 Part2 CONVENIENT OPERATION 1112 Character keyboard In the PGM 2 mode, the keyboard becomes character setting keyboard illustrated below after specifying a department, a PLU, or a clerk. 1 5 PLU DBL 1 Double size key Use this key to specify the next character to a double sized character. You must press this key before each double sized character. 2 2 Alphabet keys 3 Right arrow key 7 8 9 4 5 JKL 6 MNO 1 2 3 GHI Use this key to input the character located on the same alphabet key. Page 34 Part2 CONVENIENT OPERATION 2. Various Operations Mode Switch REG 21 Registration using preset price for Departments.

Most common causes Solutions Changing modes without complet Return mode switch to where it stops buzzing transaction.The following shows the low battery indicator. To clear this sign, press y key. Page 45 Part4 USEFUL INFORMATION GUIDELINES LAID DOWN BY FCC RULES FOR USE OF THE UNIT IN THE U.S.A. Not applicable to other areas WARNING This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. Users Manual Simple to use! 20 departments and 1200 PLUs Automatic Tax Calculations Calculator function CASIO COMPUTR CO., LTD. 62, Honmachi 1chome Shibuyaku, Tokyo, Japan CI Canada 2 INTRODUCTION Thank you very much for purchasing this CASIO electronic cash register. STARTUP is QUICK and ASY. Location Locate the Cash register on a flat, stable surface, away from heaters or areas exposed to direct sunlight, humidity or dust. Do not overload the outlet by plugging in too many appliances. Cleaning Clean the cash register exterior with a soft cloth which has been moistened with a solution of a mild neutral detergent and water, and wrung out. Be sure that the cloth is thoroughly wrung out to avoid damage to the printer. Never use paint thinner, benzene, or other volatile solvents. The mains plug on this equipment must be used to disconnect mains power. Please ensure that the socket outlet is installed near the equipment and shall be easily accessible. 2 3 INTRODUCTION Safety precautions About the icons To use this product safely and correctly, read this manual thoroughly and operate as instructed. Please keep all informations for future reference. Always observe the warnings and

cautions indicated on the product.

In this guide various icons are used to highlight safe operation of this product and to prevent injury to the operator and other personnel and also to prevent damage to property and this product. The icons and definitions are given below. Indicates that there is a risk of severe injury or death if used incorrectly. Indicates that injury or damage may result if used incorrectly. Icon examples To bring attention to risks and possible damage, the following types of icons are used. The symbol indicates that it includes some symbol for attracting attention including warning. In this triangle the actual type of precautions to be taken electric shock, in this case is indicated. The symbol indicates a prohibited action. In this symbol the actual type of prohibited actions disassembly, in this case will be indicated. The symbol indicates a restriction. In this symbol the type of actual restriction removal of the power plug from an outlet, in this case is indicated. Handling the register Warning. Should the register malfunction, start to emit smoke or a strange odor, or otherwise behave abnormally, immediately shut down the power and unplug the AC plug from the power outlet. Continued use creates the danger of fire and electric shock. Contact CASIO service representative. Do not place containers of liquids near the register and do not allow any foreign matter to get into it. Should water or other foreign matter get into the register, immediately shut down the power and unplug the AC plug from the power outlet. Continued use creates the danger of short circuit, fire and electric shock. Should you drop the register and damage it, immediately shut down the power and unplug the AC plug from the power outlet. Attempting to repair the register yourself is extremely dangerous. Never try to take the register apart or modify it in any way. Highvoltage components inside the register create the danger of fire and electric shock.

Contact CASIO service representative for all repair and maintenance. Power plug and AC outlet Use only a proper AC electric outlet. Use of an outlet with a different voltage from the rating creates the danger of malfunction, fire, and electric shock. Overloading an electric outlet creates the danger of overheating and fire. Make sure the power plug is inserted as far as it will go. Loose plugs create the danger of electric shock, overheating, and fire. Do not use the register if the plug is damaged. Never connect to a power outlet that is loose. 3 4 INTRODUCTION Warning. Contact CASIO service representative whenever the power cord or plug requires repair or maintenance. Caution! Do not place the register on an unstable or uneven surface. Doing so can cause the register especially when the drawer is open to fall, creating the danger of malfunction, fire, and electric shock. Do not place the register in the following areas. Areas where the register will be subject to large amounts of humidity or dust, or directly exposed to hot or cold air. Areas exposed to direct sunlight, in a close motor vehicle, or any other area subject to very high temperatures. The above conditions can cause malfunction, which creates the danger of fire. Do not overlay bend the power cord, do not allow it to be caught between desks or other furniture, and never place heavy objects on top of the power cord. Doing so can cause short circuit or breaking of the power cord, creating the danger of fire and electric shock. Be sure to grasp the plug when unplugging the power cord from the wall outlet. Pulling on the cord can damage it, break the wiring, or cause short, creating the danger of fire and electric shock. Never touch the plug while your hands are wet. Doing so creates the danger of electric shock. At least once a year, unplug the power plug and use a dry cloth or vacuum cleaner to clear dust from the area around the prongs of the power plug.

Never use detergent to clean the power cord, especially power plug. Keep small parts out of the reach of small children to make sure it is not swallowed accidentally. Weld lines Lines may be visible on the exterior of the product. These are weld lines that result from the plastic molding process. They are not cracks or scratches. 5 6 Getting to know your cash register 6 GTTING TO KNOW YOUR CASH RGISTR RG OP OP key Display % CAL X Note An error is generated 01 displayed whenever the position of the is changed during registration. Note that only one digit is displayed for the number of repeats. The position of the controls the type of operations you can perform on the cash

register. The PROGRAM key marked can be select any setting, while OPRATOR key marked OP can be used to select, RG or CAL only. RG CAL X OP key key In this position, the power of the cash register is off. RG Register This is the position used for registration of normal transactions. Refund This is the position used for registration of refunds. CAL Calculator This is the position used for calculator mode. Programming This is the position used to program the cash register to suit the needs of your store. X Read This is the position used to produce reports of daily sales totals without clearing the totals. Reset This is the position used to produce reports of daily sales totals. The capacity of the display is 8 digits. This part of the display can be used to show the current time or date between registration page 38. % Character Display In the character programming P2 mode, it shows the last entered character. The total T or change C appears when a subtotal, total, or change is obtained. Page nough small change in the drawer. Page Turn the to. Other 1. Troubleshooting Page43 When the cash drawer does not open. In case of power failure or the machine is in malfunction, the cash drawer does not open automatically. Caution Risk of explosion if battery is replaced by an incorrect type.

Dispose of used batteries according to the instructions. 9 9 10 Part1 QUICK START OPRATION 3. Setting the Cash Register. Set printing system as journal. Open the platen arm. Remove the core of the paper. 6. To remove journal paper. ST TABL2IF NCSSARY 5XXXX KY. 6 XXXX IS DISTRICT NUMBR 82 Input the desired flat tax rate to the appropriate department key. This procedure below programs flat tax rate only. If your tax table has break points, refer to page 25 of this manual. A Turn the mode switch to position. B nter and press the key. F Repeat step B and C to set other department key. G Press the key to end tax programming. Note In case of setting the wrong tax rate to the key, please enter. Please start with the department 2 key taxable department. Department 1 key is initialized as non taxable. Operation Printout xample 1. ntered 400 for unit price by mistake instead of 100. Quantity XX Wrong entry C h g C h XC. Multiplication Cancels the last item registered. Important Remember that when you issue a reset report, the data that is reported is cleared from the applicable totalizers. To view data without clearing totalizers, issue a read X report Financial Re port Operation h Printout50 X 0131 RG CALX FLASH X Read Symbol GROSS TOTAL QT 67 Gross Sales No. Selections A B C Select a number from list A Normal department C P3 appears in mode display For Dept. 1V Select a number from list BB For Dept. 2 Maximum No. of digits to be 5 Select a number from list C Single item sale department To end the setting Selections Normal department. B Part2 Normal sales not a single item sale department. C Set as a single item sale department 15 Status for percent key To change taxable status for the percent key xample Change Percent key registration as a Nontaxable. Program Percent Key to function as a Manual Tax key. Yes No V A Selections Maintain key buffer during receipt issue in RG mode. Reset the consecutive number to zero whenever a Daily Reset Report is issued.

Allow credit balance registration. Yes Yes No No Yes X No No C Yes V B Yes No B Yes Yes N No No M Time displays with second. Yes No Use the key as a 000 key. Cashier assignment systems sign on is used. No Yes Yes No Yes No Selections No. Yes No X Yes C No V Yes B No N Yes M C Selections No. Print Total line at finalization No Yes Single Double Single Double Selections R J R X J C R V J B R N J M A To end the setting Selections Print the time on the receipt and journal. Skip item print on journal. Yes No No No Yes X Yes No C Yes V C No No B Yes Yes N Yes No M To set report printing controls C P3 appears in mode display 23 Part2 CONVNINT OPRATION Printer switch for Receipt or Journal The printer is initialized as receipt. P appears in mode display u Select a number from list A A Selections Use the printer to print receipts. Use the printer to print a journal. C P3 appears in mode display cxn Program set code No. X p Select a number from list A nter 0 fixed code Select a number from list B To end the setting Selections Print Tax status symbols. A Do not print Tax status symbols. X Print taxable amount. Print taxable amount and tax amount for Addin. No Yes Selections Yes. No Yes X B No C 24 25 Part2 CONVNINT OPRATION 110 To program Tax Table Canadian Tax Table Type 1 Choose the tax rate from a preset tax table for British Columbia, Manitoba, Ontario, Prince

dward Island, Quebec and Saskatchewan. Part2 Note In case of setting the wrong tax rate to the key, please enter. Please start with the department 2 key taxable department. Department 2 Name DPT01 Character code 0 X P2 appears in mode display To end the setting 23. Programming department PLU PLU11200 2 30 Name CLOTHING UMBRLLA Character code X Part2 P2 appears in mode display XizVXp CizVCp To end the setting 24. Reset PLU name.

PLU11200 30 Name PLU0030 Character code 0 X P2 appears in mode display Cz p To end the setting 27 28 Part2 CONVNINT OPERATION Character keyboard 1 Double size key Use this key to specify the next character to a double sized character. You must press this key before each double sized character. 2 Alphabet keys Use these keys to input characters. Refer to the next page to enter characters. 3 Right arrow key Use this key to input the character located on the same alphabet key. This key is also used for inputting a space. 4 Delete key Use this key to delete character just entered. 5 PLU key Use this key to input PLU code. 6 Department keys Use this key to specify department. 7 Department shift key Use this key to shift department. 8 Clerk number key Use this key to input clerk number Programming department name In the 2 mode, the keyboard becomes character setting keyboard illustrated below after specifying a department, a PLU, or a clerk. 1 DBL ABC DF GHI JKL MNO PQRS TUV WXY DL 6 9 Receipt message number key u key. A Printing character Number of the digit for entering character. Number of the depression of the same key. A 01 31 32 Part2 CONVNINT OPERATION 112 Printing to read All Preset Data Operation Printout Printing preset data except PLU settings p DPT01 DPT02 Dept. When you select this function on page 21, you can get 8 cashiers or clerk sales data. For programming the key as percent minus or percent plus, see page 20. Changing modes without completing transaction. Prior to starting registration of any other Sign on operation is not performed. The following shows the low battery indicator. The power of the batteries loaded in the unit is below a certain level. The batteries loaded in the unit are dead. Important! Whenever the low battery indicator appears on the display, load a set of 2 new batteries as soon as possible. If there is a power failure or you unplug the cash register when this indicator appears, you will lose all of your sales data and settings.

Users Manual Simple to use! 20 departments and 120 PLUs Automatic Tax Calculations Calculator function CASIO COMPUTR Electronic Cash Register. M size drawer STARTUP is QUICK and EASY. For the basic settings of Warning Failure to Electronic Cash Register. S size drawer STARTUP is QUICK and EASY. For the basic settings of your Toll Free 8885990992 Operation Manual Please read carefully and follow all warnings and instructions in Please read this Instruction Manual thoroughly before use and keep in a safe place for future reference. Advanced Operations. Bluetooth and USB Playthrough This quality telephone, like all Genuine BELL products, has been designed to give you For Models DH45S DH65S No Userserviceable parts inside. Refer servicing to qualified All rights reserved. Handsfree make and receive calls using the loudspeaker. Onetouch 1571 button dials your network answering The XPK200 is a 20note MIDI Pedalboard. In order to get the most out of this instrument for many years to come, please take the Maintenance Guide Unauthorized duplication, reproduction prohibited. On behalf of the entire team at Thane Housewares, we appreciate your recent purchase of the FLAVORCHEF cooking system, which will provide you with healthy and tasty meals for Use only specified peripheral equipment and interface cables or you may experience problems. When Actual product may differ slightly to that depicted. Do not expose this equipment to dripping or splashing and ensure that no objects To get the most out of this advanced instrument for the longest possible time, we recommend Warranty card is included in this user's manual. Read and Model CPA12KH AIR CONDITIONER KXT7FXW Pulseortone dialing capability Operating Instructions Preparation Basic Operation Advanced Operation Useful Information The ECO AIR COOLER uses evaporative cooling to provide an airflow that is cooler than the Fully 60% of consumer returns No Userserviceable parts inside. Refer servicing to qualified service personnel.

WARNING To prevent When properly This is a stateofheart power monitoring socket that is highly

accurate and easy to BEFORE operation please read this user s manual carefully. Keep this manual readily available. It is ESSENTIAL YOUR FREE 2 YEAR GUARANTEE TODAY Controls 1. Power on 2. Thermostat ENGLISH Original instructions Do not expose this equip ment to dripping or splashing and ensure that no objects Owner s Manual Le socle de prise de courant doit etre installe a proximite du materiel Keep in a safe place for future reference. CONTENTS A. PRODUCT INTRODUCTION 2 B. TECHNICAL Due to continuing improvements, actual product may differ slightly from the Use handles or knobs. The lid and Please carefully read this User s Guide in particular, precautions for safety before using a product and follow instructions KSWM units We recommend that you keep this guide nearby for future reference. www.brother.com US ENG ver.0 Thank you for purchasing STI SERIES STI200, STI300, STI500, STI700, STI1000 Power Frequency Pure Sine Wave Inverter The information IMPORTANT SAFEGUARDS SAVE AND READ THESE INSTRUCTIONS When Automatic Dispensing Hot Water Pot with Reboil Function At a glance SLM 3801 OWNERS MANUAL Customer Service Tel 18002683319 Superex Canada Ltd, Toronto, M2H 3B8 Made in China Table of Contents A. Important Safety Instructions B. Charging To use this website, you must agree to our Privacy Policy, including cookie policy. After reading this guide, keep it close at hand for easy reference. Use a dry cloth to periodically wipe off any dust built up on the prongs of the plug. Humidity can cause poor insulation and create the danger of electric shock and re if dust stays on the prongs. Daily Management Report This section tells you the procedures to use to produce reports of the transaction data stored in the cash registers memory. Changing modes without completing transaction.

Casio Cash Register Pcr T290 Manual casio pcr t280 keys manual basic programming 10 extra rolls quiet and fast thermal printing 150 Used less than four years, Casio cash register PCR T290. Find art The PCRT290L also offers 58 mm thermal printer for fast 7 LPS and quiet printing. Simple to use! 15 departments..pcrt465 need instructions how to reprogram a cash register pcrt465 Hello, If anyone is looking for a Casio PCRT465 manual, head over to Ctech. For the basic settings of your cash register, please Documents Casio Qw3255 Documents Manual for Casio PCRT265 Cash Register Documents Variants of PCR Lecture 4. Colony PCR Multiplex PCR Nested PCR Reverse transcriptase PCR Quantative PCR Hot Start PCR Touch down PCR Documents Advanced PCR Dave Palmer, Byotix, Inc. Go to Casio Support Webpage and download the Owners Manual. Here. Is one available to download. Dear Lorraine, I searched a lot, but I could not locate a Casio PCR 1280 or PCR 1289 anywhere. The closest model. How do I fix problem Are you using Thermal receipt paper. Go to Casio website here for. Could somebody help me with this please Could somebody help me with this please. This machine does not have ink. It uses thermal paper. The Answer questions, earn points and help others. However, if you do not want to take up too much of your disk space, you can always download it in the future from ManualsBase. The option to print the manual has also been provided, and you can use it by clicking the link above Print the manual. If you want to quickly view the content of pages found on the following pages of the manual, you can use them. STARTUP is QUICK and EASY. Once you have mastered the QUICK START operations, you will undoubtedly want to expand your use of this machine by studying other sections of Part 2.

IMPORTANT FOR PROGRAMMING ASSISTANCE PLEASE VISIT CASIO Authorized Service Centers Power Supply If your CASIO product needs repair, or you wish You About the icons In this guide various icons are used to highlight safe operation of this product and to prevent injury to the operator and other personnel and also to prevent damage Use a dry cloth to periodically wipe off any dust built up on the prongs of the plug. Continued use of a damaged power cord can cause deterioration of the insulation, exposure of internal wiring, and short circuit, which creates the danger of electric shock and fire The PROGRAM key marked PGM CAL X Z REG can be select any Mode Switch setting, while OPERATOR key marked OP can be used to select OFF, REG or CAL only. OFF PGM RF OFF REG CAL X Z RF PGM OP key PGM key OP PGM OFF In this position, the power of the cash register is off. REG Register Important 2. Open the battery compartment cover. A Enter and

press. Daily Management Report This section tells you the procedures to use to produce reports of the transaction data stored in the cash registers memory. Important Remember that when you issue a reset Z report, the data that is reported is cleared from the applicable totalizers. Printout Operation 101 Financial Report 01082010 1650 port h X 0131 Mode Switch — Read Symbol FLASH X — Gross A B C P3 appears in mode display 1 0 4 1 2 0 5 1 VZ F or Dept. 1 Select a number Select a number from list C Select a number from list B from list A BZ F or Dept. 2 Single item sale Normal department department Maximum No. A Minus department Z No limitation for manually entered price. 7 digits. Simple to use! 20 departments and 1200 PLUs Automatic Tax Calculations Calculator function Users Manual PCRT280 Electronic Cash Register CASIO COMPUTER CO., LTD. 62, Honmachi 1-chome Shibuya-ku, Tokyo 151-8543, Japan CI Canada. Casio PCRT280 page 2 2 E INTRODUCTION IMPORT ANT FOR PROGRAMMING ASSISTANCE PLEASE VISIT usinss.

com Thank you very much for purchasing this CASIO electronic cash register. START UP is QUICK and EASY. Part 1 of this Users Manual can help you make a quick start. Once you have mastered the QUICK START operations, you will undoubtedly. About the icon. Casio PCRT280 page 4 4 E INTRODUCTION Warning. Do not allow the power cord or plug to become damaged, and never try to modify them in any way. Continued use of a. Casio PCRT280 page 5 5 E Contents Getting to know your cash register. 6 Daily Job Flow. 8 Part 1 QUICK START OPERATION. 9. Casio PCRT280 page 6 6 E Mode Switch Getting to know your cash register Note An error is generated E01 displayed whenever the position of the Mode Switch is changed during registration. The position of the Mode Switch controls the type of operations you can perform on the cash register. The PROGRAM key marked PGM can be selected any Mode Switch setting. Casio PCRT280 page 7 7 E GETTING TO KNOW YOUR CASH REGISTER Keyboard 7 1 0 4 8 2 00 5 9 3. 6 FEED PLU DEPT SHIFT ERR. Casio PCRT280 page 8 8 E Daily Job Flow Daily Job Flow Before Opening The Store 1. Plugged in 2. Enough Roll Paper Page 9 3. Date and Time is correct Page 38 4. Enough small change in the drawer. Casio PCRT280 page 11 11 Part 1 11 E Part 1 QUICK START OPERATION 5. To remove receipt paper. Casio PCRT280 page 14 14 E Part 1 QUICK START OPERATION Z X C o u X C V o B p u V y Z REG OFF RF PGM CAL Z X Mode Switch Operation 95 Charge sales You cannot perform the amount tendered operation using the u key. Corrections can be made while you are registering the item before you press a department key, or after it has already been registered. Casio PCRT280 page 15 Part 1 15 E Part 1 QUICK START OPERATION X h y B h X Z h Z B y Z h Z B B B g B B C h X X g C h X C Operation Printout 2. Entered unit price first instead of quantity and then pressed h. Multiplication Clears the last item entered.