



File Name: 9651 installation manual.pdf

Size: 2780 KB

Type: PDF, ePub, eBook

Category: Book

Uploaded: 29 May 2019, 12:33 PM

Rating: 4.6/5 from 600 votes.

Download Now!

Please check the box below to proceed.



I'm not a robot



reCAPTCHA
Privacy - Terms

Book Descriptions:

9651 installation manual

USER GUIDE 


9651

**HARDWIRED
CONTROL UNIT**



Security House show all Thank you, for helping us keep this platform clean. The editors will have a look at it as soon as possible. Contents. Compliance Statements. iiiAlarm System. 1. Keypad. 2. Proximity Tags. 2. Mains Power Failures. 4. About this Guide. 4Setting the System. 5. General Procedure. 6. Timed Set. 7. Final Door Set. 7. Silent Set. 7. Instant Set. 7. Investigating Setting Problems. 8. Detector Active. 8. Keypad is "Locked" and. Sounder is Operating. 8. Other Problems Alert orUnsetting the System. 10. To unset the system. 10. Aborting False Alarms. 10Responding to a Fire Alarm. 11. Responding to other Alarms. 11. Alarm Priority. 11Introduction. 12. All User Functions. 12. Key 1 Viewing Alerts. 12. Key 2 Omitting Zones. 13. Key 3 Requiring User CodeKey 4 To Change an Access. Code. 15. Key 5 Reading the Log. 15. Key 7 Turning the Chime OnKey 8 Testing the Sounders and. Strobe. 16. Key 9 Testing Detectors. 17. Master User Functions. 17. Key 4 Setting up Users. 17. Key 6 Setting Time and Date 22. Appendix. Log Messages. 23. Your Installation. 28This document applies to control panels using software version 6.x.The contents of this book arePrinted and published in the U.K. Part number 12275374. Page ii. Compliance Statements. The 9651PD control unit is compliant with EN501305 environmental class II. The 9651PD control unit is suitable for use in systems designed to complyThe 9941 and 9943 keypads are suitable for use in systems designed toIf the installer selects a noncompliant configuration then they must remove or adjustThere are no user serviceable parts within the keypads or the control unit. Page iii. This page is deliberately blank. Page ivAlarm System. The alarm systems described in this book comprise a control unit modelThe control unitThe detectors are installed in various places, or zones, around the premises. If something triggers a detector, the detector signals this to the control unit.<http://www.destinations-travel.org/2009/userfiles/epiphone-les-paul-manual.xml>

- 9651 installation manual, 9651 engineer manual, scantronic 9651 installation manual, cooper 9651 installation manual, 9651 alarm installation manual, cooper security 9651 installation manual, cooper menvier 9651 installation manual, scantronic 9651 installation programming manual.



How the control unit reacts depends on whether the system is set or unset. Receiving Centre ARC. Your installer can program the control unit so that you can set the system to Levels B, C and D each protect part of the premises. You cannot set more than one level at the same time. The control unit raises an alarm when a detector in a set level is triggered. Your installer allocates detector zones to levels during installation. Refer to Your premises may be fitted with 24hour zones and Hold Up Alarm zones. If Page 1 Keypad. Your alarm system is fitted with a 9941 or 9943 keypad, from which you can Figure 1 shows the main features of the keypad. The system will not accept commands from the keypad until you identify. While the system is not being accessed by a user or installer the keypad. When you enter a valid This prevents status information being Proximity Tags. So that you do not have to remember access codes your installer may have. When you hold a prox tag against a 9943 keypad, the circuit inside the tag. Each tag has one out of a possible. If the alarm system recognises the tag, it allows. If the tag is. When presenting a tag to a Ordinary users can be allocated both an access code and a prox tag. You can U01, the master user, can Page 2 These may show nothing until a user is identified. Alert lamp see page 12. Flashes to highlight Glows for acknowledged Goes out when all Service lamp. Glows if the Mains lamp. Glows when Flashes when The first line shows The second line shows. Installer configured text, The display may show Level selection Press to select Enter key. Press to Exit key. Press to Figure 1. 9941 and 9943 LCD Remote Keypads. Page 3 Mains Power Failures. The control unit indicates mains power failures using alerts. If the supply has About this Guide. <http://arrowgsc.com/userfiles/epiphone-les-paul-special-manual.xml>

USER GUIDE

9651


HARDWIRED CONTROL UNIT



The rest of this guide tells you how to use the system. Tells you how to switch off the sounders after an alarm. Tells you how to use more advanced features, some of which are described on page 4. During installation, your installer programs the system to create an exit route. When setting the system, you must follow the setting procedure. There are several different methods for setting the system. Each level can use the possible setting methods for Full Set are: Timed Set, Final Door Set. The possible setting methods for a part set are: Silent Set, Instant Set. The setting procedure is similar for each method and shown on page 6. Subsequent sections describe the specifics of each setting method. If you try to set the system while something is triggering a detector in the area, you may need to ask your installer to increase the Installer Command 182. General Procedure. To set the system, enter the correct code, try again. If you enter an incorrect code four times, the display shows for example "Set Press the appropriate level key. Note: If you press without a level key, the system sets Level A Full Set. Press to continue with the zone omitted. If you do not want to omit it, press to exit. During the exit procedure, the keypads give the tone. If you hear an intermittent tone from the keypad, leave by the designated exit route. When you complete the exit procedure, the keypad display shows which level or zone is set. Setting A. Set A. Page 6. Timed Set. With Timed Set, the system sets after a programmed exit time has expired. The time starts when you press a level key, or when you press the Final Door Set. Your installer may have programmed the system so that closing the final door starts the exit time. There is no fixed exit time. Some levels on your system may be programmed for Silent Set. The system Note: Silent Set is not available for Level A Full Set. The area protected by a level may not need an exit route or final door. With.

Instant Set, the system sets as soon as you press the appropriate key, without delay. Note: Instant Set is not available for Level A Full Set. Installer Command 182. Page 7. Investigating Setting Problems. This section offers general guidance but the configurable nature of 9651 PD means that you need to check the Detector Active. If something is triggering a detector at the end of the exit procedure, the system will not set. To set the system, go to the zone shown on the display, see Return to the keypad and set the system again. If no other detectors are active, the system sets. If other detectors are active, repeat steps 1 to 3. If the system still will not set, call your installer. Zone Open. Zone 03. If you make four incorrect attempts in a row to key in an access code, the system will wait for 90 seconds and the keypad will clear and allow you to try again. If you may need to call your installer. This feature is to prevent someone guessing an access code by simply trying the code. Note that if you continue to enter an incorrect access code the system will give an Other Problems Alert or "Spanner" LEDs Glowing. The system informs you of problems through alerts. These are warnings that your system is set up. Depending on the nature of the problem, you may need to reset the system or. Page 8. If an installer reset is required, the control unit lights the red LED. If the fault disappears, the red LED will go out. A mains power failure is an example of a technical fault that may be resolved. A standby battery failure is


For more information on viewing and acknowledging alerts, see page 12. Page 9 Unsetting the System. **WARNING** If you enter your premises and an internal alarm You must unset the system from a keypad. When you open an entry door, the system starts an entry timer. During the Your installer will To unset the system As you enter the premises, the system The display shows the level you entered Entry A If you enter an incorrect code four The entry tone stops and the system. The system or is now unset. Aborting False Alarms.



<https://www.informaquiz.it/petrgenesis1604790/status/flotaganis19052022-2213>

If you accidentally cause an alarm, you have two minutes to cancel the alarm. If the alarm goes on for longer than two minutes, the alarm will continue. **Page 10 Responding to a Fire Alarm. IMPORTANT** The system gives a fire alarm by sounding the fire alarm. Do not attempt to unset the alarm. Fire Z02 Alarm. When your system raises an alarm other than a fire alarm, you must unset the alarm. The system logs the zone or zones that triggered the alarm and displays the first zone is shown automatically when you acknowledge the alarm. For instructions on viewing and acknowledging alerts, see page 12. Your system may be configured for various types of reset. **Alarm Priority.** If more than one type of alarm occurs at the same time, then the control will sound the alarm. **Page 11 Introduction.** As well as setting and unsetting the system, you can perform a number of functions. **All Users.** Access code or tag. **Master User Only.** Access code not tag. **KeyView alerts.** Omit zones. Require user code before installer code. Change own user code. Read the log of system events. Turn chime on and off. Test the sounders and strobe. Test the detectors. Description. Create and delete users. Set the time and date. **All User Functions.** Key 1 Viewing Alerts. The system records alarms, faults and tampers as alerts. It usually displays the condition that caused the alert. If the condition no longer exists, the alert will disappear. To view alerts, press the lamp. If the lamp is glowing or flashing, there are alerts. **Page 12** The display shows the first alert for example: MAINS Fail. Inactive. Next. Lid Tamper. Battery Missing. Active. Next. Call Installer. In this case, contact your alarm company. In this case, use the system as normal. **Key 2 Omitting Zones.** Your system may be programmed so that you can omit individual detectors. This enables you to ignore alarms coming from faulty detectors in noncritical areas. Omission is not permanent when you next unset the system, the control unit will reset the zones. You must omit the zones each time you prepare to unset the system. This display shows:

<https://kairoscourse.org/images/canon-mp500-pixma-manual.pdf>



Omit Zone Page 13 If you try to omit a zone for which this is Press to exit. Omit Zone 07o. Omit Zone 07X. Note To include a zone that was omitted, follow the same procedure. Pressing toggles between omit and include. When you set the system after omitting some types of zones, a message asks Press to set the system with The zone types for which a message is displayed are Normal Alarm NA, 24hour 24, Final Exit FE, and Entry Route ER. The zone types for which a message is not displayed are Hold Up Alarm Fault BF and Fault FL. Key 3 Requiring User Code before Installer Code. You can specify that a user code must be entered before the installer code to This enables you to supervise installer activities. The display shows for example Press. Page 14 Key 4 To Change an Access Code. Note Cooper Security advise you to ensure that each user has their own access code, The display shows the user number and any text U23 User 23. If you wish to change the name, use the keypad If you do not want to change the user name then The display shows for example. Key in the new access code. The display shows User 23 Set Key 5 Reading the Log. The system keeps a log of the last 700 events. The Appendix on page 23 To view the log The display shows a message describing the. U01 Change U02 Note Neither an installer nor a user can erase the log. Page 15 In the log, user codes are represented by numbers as follows User 1. Control unit. Idle. Remote reset. Key 7 Turning the Chime On and Off. Your system may be programmed so that a chime tone sounds when certain You can turn this on and off. The display shows for example. Chime Key 8 Testing the Sounders and Strobe. You can test that the sounders and strobe are working. The system turns on Note The strobe flashes for 10 seconds to give you time to see it. Press 8 to start the test. The display shows. Test Bell. Test Strobe. Test Speaker. Test Keypad. Page 16 Key 9 Testing Detectors.

<http://excelcarebydivinee.com/images/canon-mp500-instruction-manual.pdf>

USER GUIDE

9651

HARDWIRED CONTROL UNIT



You can set the system so that it will allow you to walk around and test eachDo this when the premises are empty to avoidIf a detector fails the test, contact your alarmNotesYou cannot test Fire, 24hour, or Hold Up Alarm zones, or tamper circuits withTo test detectorsThis display showsWhen you trigger a detector, the keypad andThe display shows A for alarm, followed by theIf you trigger more than one detector, the displayPress to stop the test when you have triggeredWalk Test. A Zone 02. Master User Functions. Key 4 Setting up Users. Note Only the master user U01 can set up users. The system can store up to 50 different user access codes. Each access codeFor security, you should give one code to eachWhen the system is delivered from the factory, all access codes are set toPage 17The default access code for all users U02 through to U50 is "0000". As defaultNote Once a master user assigns a code to another user, they must instruct the userTo distinguish users and conceal their access codes, the log shows each userYou can store aThe system does not otherwiseTo aid the master user when they are editing a users name, the master userTo Create a New UserThe display showsSet Key in 0 followed by the user number. For example, if you know user number 21 is notPress. The display shows the user number and any textIf you wish to change the name, use the keypad asIf you do not want to change the name, then pressPress repeatedly until the display shows the userPage 18. U21User 21. U01 User 01. U21User 21If you do not want to change the name, then press. The display shows for exampleThe display shows forTo Delete a UserSet. Press 4. The display showsU01 User 01U21User 21If you do not want to change the name then press. The display shows for exampleUser 21The system can store up to 12 characters for each user name, includingThe default names are in the form User nn. You can change the name when you set the access code.

As part of the firstEnter letters one at a time inTo move right, press C. To move left,Page 19Move left. To delete a whole name, move to the first character and press D. When you have entered the name, press.Proximity Tags. Each normal user Users 02 to 50 can have a tag, an access code or both. You cannot assign a tag to the master user U01 or the installer U00. To Assign a Tag To a UserThe display showsSet Key in 0 followed by the user number. For example, if you wish to add a tag to userPress. The display shows the user number and any textPress and go to step 6.Press repeatedly until the display shows the userPress. The display shows for example. Present an unused

tag to the front of the keypad. Page 20 U01 User 01. User 21 The keypad gives a double beep confirmation tone To Delete a User With A Tag. Note To delete a proximity tag from the system, you must delete the user set System OK. Set The display shows Press repeatedly until the display shows the user U01 User 01. Press. The display shows for example The display shows, for example. Key in "0000". User 21 Page 21 Key 6 Setting Time and Date. Note Only the master user U01 can set the system time and date. The system uses this clock to If the mains power supply fails To set the time and date The display shows the date. Key two digits for the month 01 for January to 12 Key in two digits for the year, followed by . The display shows the time. Key in two digits for the hour followed by . Use Key in two digits for the minutes, followed by . The display shows the new time and date. Page 22 Message. Meaning. Message. AC Fail. Mains power supply Mains power supply Alarm confirmation Confirmed alarm on. User aborted alarm. Auxiliary power failed. Auxiliary power restored. Line Fault input active Line Fault input restored Control unit memory Battery reconnected. Battery failed load test. Battery disconnected. Sounder tampered with. Sounder tamper reset. Intruder alarm on zone. Access codes returned Communications failure.

<https://www.inkfactory.pk/wp-content/plugins/formcraft/file-upload/server/content/files/1627f09787813b---brother-typewriter-ax-425-manual.pdf>

Common antitamper Common antitamper System configuration Default values loaded for Control unit memory Fire alarm reset. AC Restore. Alarm Abort. AUX DC Fail. AUX DC Fail Rstr. ATE L.F. All. ATE L.F. Rstr. Bad Checksum. Batt Flt Rstr. Batt Load Fail. Batt Missing. Bell Tamper. Bell Tamper Rst. Codes Defaulted. Comms Fail. Config Change. Defaults Loaded. EEPROM Fail. Fire Reset. Meaning Fire alarm started at. Hold up alarm started in. Hold up alarm reset in Lid Tamp Restore Control unit lid tamper Lid Tamper. Control unit lid tampered. Low battery detected on. Low Batt Rstr System failed to set Soak test failed in zone. System Rearmed System rearmed after an System Startup. Power applied to system. System Tamp Rst System tamper reset. System Tamper. System tamper Page 23. Appendix. Technical alarm in zone. Line fault on telephone. Tel Line Fault Line fault reset on. Tel Line Rstr Telecmd Low Bat Low battery in 723r Panic Hold Up alarm. Telecmd PA Installer exited from Installer entered from Time and date user User Code req off No user code before User Code req on User code before Mains power supply Low battery detected on. Page 24. Power output fault in. The system locked out The system restored a Your Installation. Zone Control Unit Model. Exit Time. Bell Duration. Communicator Fitted. Description Contact Number Night Allow Page 28. It may not display this or other websites correctly. You should upgrade or use an alternative browser. I installed a 9651 in my house. I wrote down the engineer code and the zone configuration etc and all was well, for a period of time the house was rented out whilst I was away but that was years ago however it is possible I have not set the system since. On replacing the fuses and rewiring the sensors the system appears to have recovered. but. it doesnt recognise any user or engineer codes. I have been in denial over this problem for a few months but we had a powercut last night and now the control panel is making a constant bleeping.

www.cndasion.com/d/files/a-manual-for-living-epub.pdf

Im a bit scared of this procedure. If my panel has developed a fault due to the earlier short perhaps it wont survive the kickstart. Does anybody have experience with Scantronic panels losing engineer codes I have have had to do NVM reset the system quite a few times. The engineering code 7,8,9,0 is not held in the NVM and should not be lost. Do the following Take the power off the unit INCLUDING THE BATTERY your external alarm will probably go off Open the panel and REMOVE the NVM chip. Hold in the tamper switch and power the unit up with the front panel open. Keep holding the tamper in for the next few operations. Key in 1,2,3,4 Key in 0, ENTER, 7890 and then release the tamper. Power on Refit NVM Key in 9,8, ENTER Hold in the tamper again and keep holding Key in 0, ENTER, 7,8,9,0 and then release tamper You should now be able to close up the panel and reprogram. And no I didnt remember all that, it is from the installation instructions that I

have followed a few times so know it works! I did actually replace the battery when I replaced the fuses. All working again now. Thanks. Incidentally, I have been meaning to replace with a Texecom Elite panel and replace the crusty looking external sounder at the same time but it works so it's a low priority. To find out more about the cookies we use and how to control them, please visit our privacy, cookies and data protection page. When using the 9943 keypad the 9651 can be easily set and unset using proximity tag without the need to remember an access code. The 9651PD has a 70% power efficiency upgrade on its predecessor. As well as the 9651PD43 8 zone, grade 2X control panel supplied with a 09941EN43 prox keypad. We have approximately 97,000 employees. I have the installers guide and tried my best setting it up with this but can't seem to get it up and running.

There's only one door contact and 5 PIR in the system which I have set as Final Exit FE for the door and Normal Alarm NA for the PIRs, the last two zones are set as Not Used. But whenever I try to arm it, there's not a count down sound to exit and the unit just cycles through the zones and doesn't actually arm. I may resort to getting some professional in to set it up, but I was wondering if anyone can provide some guidance in case I have missed something. Have you blown a fuse. Are the PIR LEDs lighting? The PIRs seem to be working as they light up when someone is in the rooms. Which is a shame, as this is a capable panel and doesn't need to be used in this 1980s way. Just go into engineer, press 2 1 and Enter. Tick. I suppose you could have a voltage on a leg. You didn't connect the battery the wrong way round did you? I suppose you could have a voltage on a leg. You didn't connect the battery the wrong way round did you? When I remove the unit cover, the tamper internal alarm does sound and I have to punch in the code to stop it. Paste as plain text instead. Display as a link instead. Clear editor. Upload or insert images from URL.

<http://www.bouwdata.net/evenement/bose-sl2-wireless-surround-link-manual>